Nakamichi

Service Manual

Nakamichi 480

2 Head Cassette Deck



480

1. **General** 3
2. **Principle of Operation** 4
   2. 1. Mechanisms 4
      2.1.1. Headblock 4
      2.1.2. Erase Head 5
      2.1.3. Double Capstan Tape Drive 5
      2.1.4. Mechanism Control Cam Operation 6
   2. 2. Amp. Circuits 7
      2.2.1. Playback Eq. Amp. Circuit 7
      2.2.2. Record Eq. Amp. Circuit 9
      2.2.3. Bias Osc. Circuit 9
   2. 3. Mechanism Control Circuits 10
      2.3.1. Outline 10
      2.3.2. +12 V Power Source 11
      2.3.3. $\overline{\text{Power-mute}}$ Signal 11
      2.3.4. Auto Shut-off Circuit 11
      2.3.5. Record Control Circuit 14
      2.3.6. Mute Signal 14
      2.3.7. Control Motor Drive Circuit 15
      2.3.8. Reel Motor Governor 17
3. **Removal Procedures** 17
   3. 1. Cassette Case Cover Ass'y 17
   3. 2. Top Cover Ass'y 17
   3. 3. Bottom Cover Ass'y 17
   3. 4. Front Panel Ass'y 17
   3. 5. Headphone Jack Ass'y 18
   3. 6. Mechanism Ass'y 18
   3. 7. Meter Ass'y 18
   3. 8. Lamp P.C.B. R Ass'y and Lamp P.C.B. L Ass'y 18
   3. 9. Main P.C.B. Ass'y 19
   3. 10. Control Switch Holder Ass'y 19
   3. 11. Switch P.C.B. Ass'y 19
   3. 12. Volume P.C.B. Ass'y and Control Switch P.C.B. Ass'y 19
   3. 13. Rear Panel Ass'y, Power Transformer and Power Switch 19
   3. 14. Cassette Case Ass'y and Cover Plate Ass'y 20
   3. 15. Tape Counter Ass'y 20
   3. 16. Capstan Motor Ass'y and Flywheel Ass'y 21
   3. 17. Sub Mechanism Chassis Ass'y 21
   3. 18. Control Motor Ass'y and Reel Motor Ass'y 21
   3. 19. Cam Control Volume 21
   3. 20. Reel Hub Ass'y and Idler Ass'y 21
   3. 21. Cam Drive Gear and Control Cam 21
   3. 22. Head Mount Base Ass'y 21
   3. 23. Pressure Roller Ass'y and Erase Head 22
   3. 24. Record/Playback Head Ass'y 22
4. **Measurement Instruments** 23
5. **Mechanical Adjustments** 24
   5. 1. Mechanism Control Cam Adjustment 24
   5. 2. Tape Speed Adjustment 25
   5. 3. Record/Playback Head Tilt Adjustment 25
   5. 4. Head Base Stroke Adjustment 26
   5. 5. Tape Guides Adjustment and Erase Head Stroke Adjustment 27
   5. 6. Erase Head Height and Tilt Adjustment 28
   5. 7. Record/Playback Head Height Adjustment and Azimuth Alignment 28
   5. 8. Tape Travelling Adjustment 29
   5. 9. Record Switch Linkage Adjustment 29

5. 10. Flywheel Holder Adjustment 30
5. 11. Eject Wire Adjustment 30
5. 12. Lubrication 30
6. Parts Location for Electrical Adjustment 31
7. Electrical Adjustments and Measurements 32
7. 1. Adjustment and Measurement Instructions 32
7. 2. Playback Frequency Response Adjustment 35
7. 3. Check on Dolby NR Circuit 35
8. Mounting Diagrams and Parts List 36
8. 1. Volume P.C.B. Ass'y 36
8. 2. Control Switch P.C.B. Ass'y 36
8. 3. Switch P.C.B. Ass'y 36
8. 4. Control P.C.B. Ass'y 36
8. 5. Auto Shut-off P.C.B. Ass'y 36
8. 6. Lamp P.C.B. L Ass'y 36
8. 7. Lamp P.C.B. R Ass'y 36
8. 8. Main P.C.B. Ass'y 37
9. Mechanism Ass'y and Parts List 41
9. 1. Synthesis 41
9. 2. Front Panel Ass'y (A01) 41
9. 3. Synthesis Mechanism Ass'y (A02) 41
9. 4. Meter Escutcheon Ass'y (B01) 42
9. 5. Control Switch Holder Ass'y (B02) 43
9. 6. Headphone Jack Ass'y (B03) 43
9. 7. Mechanism Ass'y 480 (B04) 44
9. 8. Chassis Ass'y (B05) 45
9. 9. Flywheel Holder Ass'y (C01) 45
9. 10. Sub Mechanism Chassis Ass'y (C02) 46
9. 11. Main Mechanism Chassis Ass'y (C03) 48
9. 12. Rear Panel Ass'y (D01) 49
9. 13. Reel Motor Ass'y (E01) 50
9. 14. Control Motor Ass'y (E02) 50
9. 15. Head Mount Base Ass'y (F01) 50
9. 16. Supply Pressure Roller Ass'y (F02) 50
9. 17. Take-up Pressure Roller Ass'y (F03) 50
9. 18. Head Base Ass'y C (F04) 51
9. 19. Cassette Case Holder L Ass'y (F05) 51
9. 20. Cassette Case Holder R Ass'y (F06) 51
9. 21. Auto Shut-off Ass'y (F07) 51
9. 22. Pneumatic Damper Ass'y (F08) 51
9. 23. RP-9E Record/Playback Head Ass'y (G01) 51
10. Overall Timing Chart 53
11. Eq. Amp. Frequency Response 54
11. 1. Playback Frequency Response 54
11. 2. Record Current Frequency Response 54
12. Wiring Diagram 55
13. Block Diagrams 57
13. 1. Amplifier 57
13. 2. Mechanism Control 58
14. Schematic Diagrams 59
15. Specifications 62

1. GENERAL

1.1. Control Functions

Nakamichi 480 control functions are shown below:



Fig. 1.1 Front View



Fig. 1.2 Rear View

1. Power Switch
2. Cassette Lid
3. Eject Button
4. Tape Counter
5. Counter Reset Button
6. Input Level Control - Left Channel
7. Peak Level Meters
8. Input Level Control - Right Channel
9. Dolby NR Switch
10. Eq. Switch
11. MPX Filter Switch
12. Tape Selector Switches
13. Tape Memory Switch
14. Pause Button
15. Fast-Forward Button
16. Play Button
17. Stop Button
18. Rewind Button
19. Record Button
20. Headphone Jack
21. Input Jacks
22. Output Jacks
23. Remote Control Socket
24. Voltage Selector Switch
25. Power Cord

1.2. Voltage Selector

Voltage selector is installed on the rear panel for other versions of the Nakamichi 480.
This voltage selector can select either 120 V or 220 – 240 V at customer's disposal.

2. PRINCIPLE OF OPERATION

2.1. Mechanisms

2.1.1. Headblock

Refer to Fig. 2.1.1 Headblock.

Nakamichi 480 Headblock provides more stabilized tape travel.

Accuracy of tape travel is one of the most essential factors for a device to optimize its performance. Inaccurate tape travel will therefore induce deterioration exemplified by the following:

(a) vibration will be given to tape travel, as a result of which flutter and modulation noise will become increased

(b) insufficient tape-to-head contact will result in level drops

(c) tape skew will become greater and frequency response will become decreased

Needless to say, constant tape travel must consist of smooth drive mechanism, as well as of the fact that tape, heads and tape guide are placed in the most appropriate positions.

N-480 Record/Playback Head is made small in size. Erase Head is located at the place where the Record Head is located in the N-700II/1000II.

Record/Playback Head is assembled on the Head Mount Base. Take-up Tape Guide and Supply Tape Guide are fixed to the Take-up and Supply Pressure Rollers respectively. Erase Head is placed on the Head Base. All these can be separately adjusted. Shape of the Heads and its location have been carefully studied to bring about smoother contact of tape with the Heads. Pad Lifter is affixed to the Record/Playback Head so as not to let Tape Pad touch the Head to give more stabilized tape travel, making it free from the influence of the Tape Pad within the Cassette Tape. Thus the trouble of changes in azimuth can now be avoided at changing of cassette tape, if only the Record Head azimuth is properly adjusted in advance.

(1) Adjustment of Tape Guide Height

Tape Guides for the N-480 are affixed to the Supply Pressure Roller Ass'y and Take-up Pressure Roller Ass'y. With springs in the studs of Main Mechanism Chassis Ass'y, the Supply Pressure Roller Ass'y and Take-up Pressure Roller Ass'y are tightly affixed with Tape Guide Adjustment Nuts. The Adjustment Nuts are placed on the springs, and therefore either by tightening or loosening, height adjustment of the Tape Guides will become possible.

(2) Record/Playback Head Height Adjustment and Azimuth Alignment

Azimuth and height of Record/Playback Head are independent from each other and adjustment may be done separately without affecting others. In order to adjust the tilt of Record/Playback Head backwards or frontwards, take off the Height Gear Stopper and take out the Height Gear and then turn the two Height Adjustment Screws. After completion of adjustment, place the Height Gear back and fix it with the Height Gear Stopper. After the tilt is adjusted in such a way as above, adjust the height by turning the Height Gear. Azimuth is aligned by turning the Azimuth Alignment Screw. This system has been carefully designed so as to minimize influence each other between azimuth alignment and height adjustment.

(3) Erase Head Height and Tilt Adjustment

Erase Head is affixed onto the Erase Head Plate which is assembled with the Head Base. It is installed with three screws. By turning these screws, its height, tilt of backward or frontward, and tilt of leftward or rightward can be adjusted separately, thus the best location of Erase Head can be obtained.



Fig. 2.1.1 Headblock

2.1.2. Erase Head

Fig. 2.1.2 shows the sectional view of the Erase Head. Fig. 2.1.3 shows the characteristics of erasing current and erasure.

It has the same characteristics with the previous type Direct-Flux Erase Head but been purposely developed to minimize the size further.

Conventional Erase Head had its inside core narrower than its outside core, while this Erase Head is equipped with an inside core wider than the outside core. This has resulted more power sufficient enough for erasing with small power consumption, approx. 0.5 W, though the head width is as small as 3 mm. The smaller the power consumption is, the smaller will be the heat generation, and this is of course another merit.



Fig. 2.1.2 Sectional View of Erase Head



Fig. 2.1.3 Characteristics of Erasing Current and Erasure

2.1.3. Double Capstan Tape Drive

As shown in Fig. 2.1.4, the double capstan system consists of two capstan shafts (a) and (b) connected to the two flywheels which are driven by a capstan belt.

Against these capstans two pressure rollers (a) and (b) are engaged to run the tape with an adequate holdback tension created by the double capstan and pressure rollers. Since the diameter of capstan shaft (a) is smaller than that of capstan shaft (b), when two flywheels begin to turn as shown in the figure, capstan (a) runs slightly faster than capstan (b), which subsequently generates holdback tension.

As you note, if the diameters of the 2 capstans should be the same, the generation cycles of wow and flutter will become approximately the same, as a result of which defective portion will be doubly superposed and preferable portion vice versa. The N-480 employs 2 capstans, each having different diameter and rotations, thereby avoiding the aforesaid occurrence and stabilizing wow and flutter characteristics.

As the double capstan system always creates a constant and stable holdback tension between the two capstans, the condition of the tape between two capstans will not be affected by any external conditions such as irregular take-up and supply torques, irregular loading of cassette tape, undesirable mechanism vibration and etc., thus assuring the superior wow and flutter characteristics. The double capstan system provides a constant holdback tension on the tape and maintains the stable pressure onto the tape against the heads.

The only critical factor in the double capstan system is to be considered; the two capstans have to be positioned perfectly in parallel and to be precisely vertical against the head base, the pressure rollers have to be evenly pressed against the capstan shafts and the head surface must be positioned perfectly vertical to the tape surface. Otherwise, the running tape might become out of the tape guide resulting in irregular movement.



Fig. 2.1.4 Double Capstan Tape Drive

2.1.4. Mechanism Control Cam Operation

Refer to Fig. 2.1.5 Mechanism Control Cam timing chart. Function of N-480 Mechanism is done by Cam Control. Cam is driven by the Control Motor. The Motor operates so as to result zero in the difference of voltages between each voltage corresponding to mechanism function and each reference voltage which corresponds to each commands of the Control Switch. When the difference comes to zero, then it stops. In this way, each function is kept properly operated. For further details, please see the explanation on Logic Control. Here we explain principle of its mechanical functions.

Cam Control System works as follows: Cam Drive Gear is driven by Control Motor by means of Drive Belt. Cam Drive Gear is related to the cam with which each function may be mechanically set on.

(1) Play Mode

Press the Play Switch to make it Play mode. Then the Cam begins to move from Stop position to Play position and the Play mode will be set.

The Head Base which is linked to the Cam and which is normally pushed against the Stop position gets released and the Head Base will slowly come out for playing. To explain this function, first the Head Base is latched and the Reel Motor begins to turn. Then the Pressure Roller will be pushed and the Brake will be released. Now the tape begins to run. If you press the Pause Switch at this stage, it comes to Pause mode. Brake operates and the Pressure Roller moves away from the Capstan and the Reel Motor stops.

Play mode may be changed to Stop mode by pressing the Stop Switch, and latch of the Head Base being released. The Cassette Case cannot be opened because of the latched eject effect unless it is in Stop mode.

(2) Record Mode

By pressing the Record Switch and the Pause or Play Switch, it may be made to Record mode. The Cam at this moment moves from Stop position to Rec. position. At the same time, Rec. Trigger Mechanism is driven and the Record Switch on the Main P.C.B. is switched on to the Record side. Further, the Cam turns until it comes to the Pause or Play position. On the other hand, the Rec. Trigger Mechanism is released during this process. When the Cam is set in Rec./Pause or Rec./Play position, Record signals will be sent to Bias Oscillating Circuit from Logic Control Circuit to let the Bias to oscillate.

Press the Stop Switch and the Cam comes back to the Stop position. At the same time, it will set the Record Switch on the Main P.C.B. to the Play side.

(3) F.F. or Rewind Mode

By pressing the F.F. or Rewind Switch, it comes either to F.F. or Rewind mode. The only difference of these two modes is that one is to turn the Reel Motor reverse and the other to transmit the torque against the Reel Hub onto the take-up side or to the supply side. Brake is released at this stage and the Reel Motor begins to turn F.F. or Rewind.

(4) Pause Mode

Press the Pause Switch to make it to Pause mode. In changing it from Stop mode to Pause mode, the Brake is first released, then the Head Base is latched, and again the Brake works.

At this stage, the Reel Motor would not turn with the Pressure Roller being apart from the Capstan, and the tape would remain still.



Fig. 2.1.5 Mechanism Control Cam Timing Chart

2.2. Amp. Circuits

2.2.1. Playback Eq. Amp. Circuit

Fig. 2.2.1 shows the playback equalizer circuit, and Fig. 2.2.2 shows the system diagram.

Fig. 2.2.3 shows the time constant of equalizer. The playback head is connected with circuit's input.

Amplifier (Q101 and Q102) is an equalizer amplifier and its time constant is illustrated in Fig. 2.2.3. R111, R112, L101, and C109 compose a peaking circuit. This circuit compensates the gap loss of the playback head so that high-frequency response will be improved.

Playback Eq. Amp. gain is adjusted by semi-fixed volume VR101 (VR201) to obtain 100 mV output level at TP101 (TP201) when 400 Hz Level Tape (DA09005A) is being played back. Equalizer Switch (70 μs/120 μs) is connected with Amp. The overall time constants in Playback Eq. Amp. are as follows:

Eq. SW – 70 μs
3180 μs (50 Hz) + 70 μs (2274 Hz)
Eq. SW – 120 μs
3180 μs (50 Hz) + 120 μs (1326 Hz)

Shown below is the table for the position of Tape Switch and Eq. Switch:

Tape SW	Eq. SW	Tape
ZX	70 μs	Nakamichi ZX
SX	70 μs	Nakamichi SX, TDK SA, Maxell XL-II Scotch Master 70 μs
EX	120 μs	Low-Noise High-Density (including EX, EXII, TDK AD, Maxell XL-I, Scotch Master 120 μs)
	70 μs	Nakamichi EX, EXII

It is specified in the IEC Standard that the time constant is 120 μs on tapes of ferric oxide, and 70 μs on tapes of CrO2.
However, in the case of Eq. Switch on the N-480, when time constant at playback is changed, at the same time time constant at record must also be changed.
Therefore, even though record and playback is made by the method other than the IEC Standard, no deterioration of frequency response or level difference will occur. (Any other method for instance, record and playback on ferric oxide tape with putting Tape Switch on EX and Eq. Switch on at 70 μs.)
When Nakamichi EX or EXII Tape is used at Tape Switch: EX, and Eq. Switch: 70 μs, S/N ratio will be improved by approximately 4 dB (WTD).



Fig. 2.2.1 Playback Eq. Circuit



Fig. 2.2.2 System Diagram



Fig. 2.2.3 Time Constant

2.2.2. Record Equalizer Amplifier Circuit

The record equalizer amplifier circuit consists of the Output Amp. incorporated in the Dolby NR IC and peripheral circuits as shown in Fig. 2.2.4.

VR102, VR103, and VR104 are the record calibration semi-fixed volumes for ZX, SX, and EX tapes. The output of the Output Amp. is given to these volumes, and the outputs from the volumes are fed back to the inverting input of the Output Amp. via amplifier Q103 and a time-constant changeover circuit.

By adjusting L104, compensation for the high frequency range is made by setting a resonance frequency at 21 kHz or neighborhood.

L105, C138 and C139 compose a recording bias trap circuit.

2.2.3. Bias Osc. Circuit

Fig. 2.2.5 shows a push-pull oscillator with an oscillation frequency of 105 kHz which is constructed by capacitors C302 and C303 coupling the collectors and bases of two transistors (Q301 and Q302).

This is used to provide recording bias and as an erase signal.

By pressing the Record and Pause, or Record and Play buttons, (Play + Pause)-Position signal conducted from the logic control circuit becomes H and Q303 turns to ON.

Therefore, +24 V is applied to the circuit and oscillation begins.

When the record mode is released, oscillator output is damped by the discharge of C304. This prevents magnetization of the head.



Fig. 2.2.4 Record Eq. Amp. Circuit



Fig. 2.2.5 Bias Osc. Circuit

2.3. Mechanism Control Circuits

2.3.1. Outline

(1) Control Button Operation

Record, Rewind, Stop, Play, and Fast-Forward Buttons consist of a 5-way switch and are interlocked each other. When one button is pressed, it is mechanically locked in the ON state and other buttons are mechanically released. Stop Button is of momentary type and acts to release other buttons mechanically. But it is not used to control circuits electrically. Pause Button is independent from others and is of push-on and push-off type. Note that if two or more buttons are pressed simultaneously, these buttons are locked in the ON state. Under the normal control button operation, only Record and Play Buttons are pressed simultaneously to set the N-480 in RECORD mode. In this case, both Record and Play Buttons are locked in the ON state and RECORD mode is set. The N-480 is designed so as not to occur erroneous operation even if two or more buttons are pressed simultaneously. Further, to prevent from abnormal tape tension, loosening of tape, etc., the N-480 changes its mode by passing through momentary STOP mode automatically, for example, when PLAYBACK mode is commanded while FF mode, or REW mode is commanded while FF mode.

(2) Auto Shut-off Function

Refer to Fig. 2.3.1 basic circuit diagram.

During FF, REW, or PLAY (PLAYBACK or RECORD) mode, auto shut-off will be activated when the tape comes to end, and FF, REW, or PLAY mode is changed to STOP mode.

Following explanation is made in regard to REW mode:

In the initial condition, Q428 is turned ON and +24 VS is applied to the emitter of Q402. When Rewind Button is pressed, it is locked in the ON state, as a result, Q402 is turned ON, the REW signal becomes H, and the N-480 is set in REW mode.

When tape-end comes, auto shut-off is activated and Q428 is turned OFF, as a result, +24 VS is shut-off, Q402 is cut off, and the REW signal becomes L. In this way, REW mode is changed to STOP mode. (Note that Rewind Button is still locked in the ON state.) When Play Button is pressed in this state, REW Button is released and Q428 is turned ON, as a result, +24 VS is applied again, Q418 is turned ON, the PLAY signal becomes H, and the N-480 is set in PLAY mode.

(3) Unattended Recording or Playback

Unattended recording or playback is carried out by the use of the lock mechanism of control button, therefore, no special circuit is required for this purpose.

If Record and Play Buttons are pressed, unattended recording can be carried out when the power is connected to the N-480. If only Play Button is pressed, playback will be carried out when the power is connected to the N-480.



Fig. 2.3.1 Basic Auto Shut-off Circuit

2.3.2. +12 V Power Source

Refer to Fig. 2.3.2 circuit diagram. Only +24 V DC power supply is used in the N-480. The circuit acts to produce a +12 V power source from the +24 V DC power supply. Mechanism control is done by using thus produced +12 V.



Fig. 2.3.2 +12 V Power Source Circuit

2.3.3. Power-mute Signal

Refer to Fig. 2.3.3 circuit diagram and Fig. 2.3.4 timing chart. Power-mute = L signal is produced pulse-likely when Power Switch is turned ON or OFF. This L pulse mutes the amp. circuit and also acts to shut off the shut-off circuit initially.

(1) Power Switch ON

Q433 is turned ON at every positive half cycle of the output from the secondary winding of the power transformer. When Q433 is turned ON, C416 is discharged, as a result, the voltage of C416 can not exceed the VBE of Q432, and Q432 is in the cutoff state.

Therefore, the Power-mute = L pulse is produced for a certain period of time when +24 V is built up after Power Switch is turned ON.

The Power-mute = L signal makes Q416 to turn ON, as a result, Mute signal becomes H and the amp. circuit is muted.



Fig. 2.3.3 Power-mute Circuit

Meanwhile, the Power-mute = L pulse is applied to the shut-off circuit and shut-off is activated.

(2) Power Switch OFF

The output from the secondary winding of the power transformer ceases quickly, and Q433 is turned OFF. Consequently, the base current flows to Q432 through R481, Q432 is turned ON, and the Power-mute signal becomes L.

The Power-mute = L signal makes Q416 to turn ON, as a result, Mute signal becomes H and the amp. circuit is muted. At the same time, shut-off circuit is shut off by the Power-mute = L signal.



Fig. 2.3.4 Timing Chart

2.3.4. Auto Shut-off Circuit

Refer to Fig. 2.3.5 circuit diagram and Fig. 2.3.6 timing chart.

(1) Shut-off Sensor

Light from lamp PL407 is projected through holes in a disc rotating synchronously with the take-up reel, and the intermittent flashes coming through the disc are converted into electrical signals by a phototransistor Q450. These signals are amplified into square waves, and transmitted to the shut-off detecting circuit in the subsequent stage. When the tape-end comes, the take-up reel and the disc stops rotating, and no pulse is output from the sensor.

(2) Shut-off Detecting Circuit and Peripheral Circuits

Shut-off conditions are as follows:

- reached tape-end during PLAY (PLAYBACK or RECORD), FF, or REW mode
- mode is changed as follows:
  - from FF to REW mode, or vice versa
  - from FF to PLAY mode
  - from RECORD mode to FF or REW mode

  When the mode is changed, shut-off is momentarily activated and the mode is changed to STOP mode in a short period of time, and after this STOP mode is over, a new mode is set.
- Power-mute = L pulse is generated when Power Switch is turned ON or OFF
- memory rewind function is activated.

(a) Reached tape-end during PLAY (PLAYBACK or RECORD), FF, or REW mode

Explanation is made for PLAY mode as an example. For FF or REW mode, the shut-off function is the same as for PLAY mode.

As Play Button is locked ON mechanically, $\overline{\text{Kplay}}$ = L. Accordingly, R488 (100 kΩ) is grounded through Play Button and the voltage at the point A becomes approx. +23 V. Since the voltage at the point A is not lower than the emitter voltage of Q424, Q424 is turned OFF and Q426 is also turned OFF. (Q424 and Q426 will be turned ON when the voltage at the point A is further lowered as described in subsequent (b).)

Q425, Q427, Q430, R470 and C412 consist of a shut-off detecting circuit. During PLAY mode, the voltage at the point A is approx. +23 V, therefore, Q425 is turned ON and C412 (2.2 μF) is charged toward +24 V through R470.

Meanwhile, pulses from the shut-off sensor are applied to the base of Q427 through R489 and C418, and, at every H cycle of the sensor output pulse, Q427 is turned ON and C412 is discharged through Q427. When the tape-end is detected, pulses from the shut-off sensor are not transmitted and Q427 is turned OFF, resulting in C412 being charged continuously.

When the voltage of C412 exceeds the sum of the emitter voltage (approx. 5.5 V) and the VBE of Q430, Q430 is turned ON and the base current flows to Q429. Consequently, Q429 is turned ON, Q428 is cut off, +24 VS is shut-off, PLAY mode is changed to STOP mode, and play lamp goes out.

Q430, Q429, Q428, R476, R474, R456 and C420 consist of a Schmitt circuit which provides hysteresis characteristics for ON/OFF of Q430. Accordingly, Q430 will be turned ON or OFF without chattering for the input waveform with a large time constant developed across C412. If Pause Button is pressed during PLAY mode, tape stops and no pulse is transmitted from the shut-off sensor, but Q427 is kept ON since Q423 is turned ON during PLAY·PAUSE mode, therefore, no charge is made at C412 and shut-off is not activated.

When shut-off is made at the tape-end during PLAY mode, PLAY mode is changed to STOP mode.

If Stop Button is further pressed, Play Button will be released and the voltage at the point A returns to +24 V as R488 is released from grounding, as a result, Q425 is turned OFF and C412 is discharged quickly through D423 and R467 (10 kΩ). Accordingly, Q430 is turned OFF, Q429 is turned OFF, Q428 is turned ON, and +24 VS is again applied preparing for the next control button operation.



Fig. 2.3.6 Timing Chart



Fig. 2.3.5 Auto Shut-off Circuit

(b) Mode is changed

1) From FF to REW mode, or vice versa, or from FF to PLAY mode

Refer to Fig. 2.3.7 timing chart.

When mode is changed from FF to REW mode, or vice versa, or from FF to PLAY mode, momentary STOP mode is automatically taken in view of the response of the tape deck mechanism, and after this is over, a new mode is set.

The following explains in regard to the case when FF mode is changed to PLAY mode by pressing Play Button during FF mode:

During FF mode, R486 (100 kΩ) is grounded by the $\overline{\text{Kf.f.}}$ = L signal. When Play Button is pressed, it is locked ON and FF Button is released. Although FF Button is released, the $\overline{\text{Kf.f.}}$ signal is kept L for a short period of time because the delay circuit (C605 and R608) connected in parallel to FF Button acts to prolong the $\overline{\text{Kf.f.}}$ = L signal. In this period, the voltage at the point A becomes approx. +22 V from +23 V pulse-likely as R486 and R488 are grounded by the $\overline{\text{Kf.f.}}$ = L and $\overline{\text{Kplay}}$ = L signals respectively. Consequently, Q424 and Q426 are turned ON, and C411 is charged up to +24 V, but C411 will be discharged after this period is over. The base current to Q430 is supplied from C411 through D424 and R475, as a result, Q430 and Q429 are turned ON, Q428 is turned OFF, and +24 VS is shut off resulting in STOP mode. On the other hand, since the base current to Q427 is supplied from C411 through R469, R427 is turned ON until the discharge of C411 is completed. When the voltage of C411 is lowered than the emitter voltage (approx. 4.2 V) of Q430, Q430 and Q429 are cut off, Q428 is turned ON, and +24 VS is supplied, as a result, the PLAY signal becomes H (+24 VS) and PLAY mode is set.

2) From RECORD mode to FF or REW mode

When mode is changed from RECORD to FF or REW mode, momentary STOP mode is automatically taken in view of the tape deck mechanism, and after this is over, a new mode is set.

When Record Button is released by pressing either FF or REW Button, Q419 is turned from ON to OFF, therefore, a negative differentiated pulse is applied to the point A via C421 (22 μF).

This negative pulse acts to turn ON Q424 and Q426, as a result, C411 is charged up to +24 V. FF or REW mode is set after passing through a certain period of STOP mode in the same manner as above 1).

(c) $\overline{\text{Power-mute}}$ = L

The $\overline{\text{Power-mute}}$ = L pulse is generated when Power Switch is turned ON or OFF. During the $\overline{\text{Power-mute}}$ signal is L, the voltage at the point A becomes lower than the emitter voltage of Q424. Subsequently, Q424 and Q426 are turned ON, C411 is charged up to +24 V, and shut-off is activated in the same manner as above (b).

(d) Memory Rewind

During REW mode and with Memory Rewind Switch turned ON, C414 is grounded when the tape counter comes to "999", and Q431 is turned ON pulse-likely.

As a result, Q430 is turned ON, and shut-off is activated resulting in STOP mode.



Fig. 2.3.7 Timing Chart

2.3.5. Record Control Circuit

Refer to Fig. 2.3.8 circuit diagram.

RECORD mode is set by pressing Record Button, then Play Button together. By pressing Record Button, the $\overline{\text{Krec.}}$ signal becomes L, Q419 is turned ON, Q421 is turned ON, and the record lamp is illuminating. Then, by pressing Play Button further, the $\overline{\text{Kplay}}$ signal becomes L, Q418 is turned ON, the PLAY signal becomes H (+24 VS), and Q420 is turned ON.

Accordingly, the base current flows to Q403 via C406 connected to the base of Q403, and Q403 is turned ON pulse-likely.

The output of Q403 is fed to the control motor drive circuit and acts to bring the cam to the record position.

When Q403 returns to OFF, the cam then moves to the play position and stays there, thus the mechanism is set to RECORD mode.

Record circuit is designed to protect from the erroneous setting of RECORD mode even if wrong record button operation is made.

Q422 is turned ON during FF or REW mode, or when the cam is set to the play or pause position, i.e., PLAY or PLAY/PAUSE mode. In this case, as D422 is grounded by Q422, Q421 is not turned ON and the record lamp is not lit even if Record Button is further pressed.

Further, the base of Q420 is grounded via D419 and Q422, consequently, Q420 and Q403 are not turned ON and no pulse is output from Q403 to the control motor drive circuit.



Fig. 2.3.8 Record Control Circuit

2.3.6. Mute Signal

Refer to Fig. 2.3.9 circuit diagram.

When Q416 is turned ON, the Mute = H signal is fed to the amp. circuit and the amp. circuit is muted.

The condition that the amplifier circuit is muted are (Mute = H):

Q416 ON = ((Q412 ON) + $\overline{\text{PLAY}}$)·(R/P Switch = Play) + Power-mute

Power-mute: When Power Switch is turned ON or OFF, $\overline{\text{Power-mute}}$ signal becomes L, i.e., Power-mute signal becomes H, and Q416 is turned ON.

Q412 ON : Cam is in the pause position.

Q412 OFF : Cam is in the play position (i.e., PLAYBACK or RECORD mode).

R/P Switch : When R/P Switch on the Main P.C.B. is in the record position, +24 V is applied, but when it is in the play position, no voltage is applied.

The modes in which the amplifier circuit is not muted are (Mute = L):

Q416 OFF = $\overline{\text{Q416 ON}}$

= $\overline{((\text{Q412 ON})\cdot\text{PLAY} + (\text{R/P Switch} = \text{Play}))\cdot\text{Power-mute}}$

= $\overline{((\text{Q412 OFF})\cdot\text{PLAY} + (\text{R/P Switch} = \text{Record}))\cdot\text{Power-mute}}$

i.e., PLAYBACK mode and RECORD mode.



Fig. 2.3.9 Mute Signal Circuit

2.3.7. Control Motor Drive Circuit

Refer to Fig. 2.3.10 circuit diagram and Fig. 2.3.11 timing chart. The control motor is turned by varying amounts, according to which control button is set. This motor is connected to the mechanism control cam, and the mechanism is set to the mode indicated by this cam.

The motor is driven by the differential amplifier IC402 (1/2) and drivers Q405 and Q406. In the control motor stop condition, both voltages at pins No.5 (non-inverting input) and No.6 (inverting input) of IC402 (1/2) are equal and the difference of both inputs is zero. When a new mode is demanded, the balance of both inputs is broken, as a result, the control motor is driven until both inputs are balanced. The cam control variable resistor VR601 moves synchronously with the motor so that the voltage at the sliding contact of VR601 is changed.

When the voltage at the sliding contact of VR601 is changed and the input difference of the differential amplifier IC402 (1/2) becomes zero, the control motor stops.

The following table shows the relationship between cam position and the voltage at the sliding contact of the cam control variable resistor VR601, and the state of transistors in each mode.

Position on Cam	Typical Voltage at Sliding Contact of Cam Control Volume
Record	16V
Stop	15V
FF/REW	13.5V
Pause	10V
Play	7.5V

Mode	ON		OFF	
Record	Q403, Q410 ⎍	Q412	Q404	Q411
Stop		Q412	Q403, Q404, Q410	Q411
FF/REW	Q404, Q410	Q412	Q403	Q411
Play·Pause	D417 ON	Q411, Q412	Q403, Q404, Q410	
Play		Q411	Q403, Q404, Q410	Q412





Fig. 2.3.10 Control Motor Drive Circuit



Fig. 2.3.11 Timing Chart

2.3.8. Reel Motor Governor

Refer to Fig. 2.3.12 circuit diagram.

One end of the reel motor is connected with +12 V and the other end is a terminal for controlling.

During FF mode, Q413 is turned ON and the reel motor is grounded. Accordingly, the reel motor turns in the direction of fast-forwarding. On the other hand, during REW mode, +24 V (REW = H) is applied to the reel motor and the reel motor turns in the direction of rewinding. During PLAY (PLAYBACK or RECORD) mode, Q412 is turned OFF and the Pause-position signal becomes H, as a result, Q417 is turned OFF and the reel motor is turned at a constant speed by the governor composed of Q414 and Q415.

During PLAY/PAUSE mode, Q412 is turned ON and the Pause-position signal becomes L, therefore, Q417 is turned ON, Q414 is biased in the reverse direction, and Q414 is cut off, thus the reel motor does not turn.

Take-up function at loading:

When a cassette tape is inserted and loaded, Eject Switch will become open. Consequently, the base current is applied to Q413 through C409, and Q413 is turned ON pulse-likely. During Q413 is turned ON, the reel motor turns in the direction of fast-forwarding and eliminates tape loosening of the cassette tape if any.



Fig. 2.3.12 Reel Motor Governor

3. REMOVAL PROCEDURES

3.1. Cassette Case Cover Ass'y

Refer to Fig. 3.1.

(1) Press the Eject Button to open the Cassette Case Ass'y.
(2) Pull out F01 (Cassette Case Cover Ass'y) upwardly.

3.2. Top Cover Ass'y

Refer to Fig. 3.1.

Remove F02 and F03, then disassemble F04 (Top Cover Ass'y).

3.3. Bottom Cover Ass'y

Refer to Fig. 3.1.

Remove F05, then disassemble F06 (Bottom Cover Ass'y).

3.4. Front Panel Ass'y

Refer to Fig. 3.2.

(1) Refer to Fig. 3.1. Remove Top Cover Ass'y and Bottom Cover Ass'y referring to items 3.2 and 3.3.
(2) Pull out F01 (Volume Knobs).
(3) Remove F02 (Power Switch Joint Bar) by releasing the self-interlocking pin of the Power Switch Joint Bar from Power Switch, and turn F02 (Power Switch Joint Bar) by 90° either clockwise or counterclockwise, then disassemble F02 (Power Switch Joint Bar) from the Power Switch Knob Ass'y.
(4) Remove F03, then disassemble F04 (Front Panel Ass'y).



Fig. 3.1

3.5. Headphone Jack Ass'y

Refer to Fig. 3.2.

(1) Remove Front Panel Ass'y referring to item 3.4.
(2) Remove F05, then disassemble F06 (Headphone Jack Ass'y).

3.6. Mechanism Ass'y

Refer to Fig. 3.2.

(1) Remove Front Panel Ass'y referring to item 3.4.
(2) Remove F07 and F08, then disassemble F09 (Mechanism Ass'y including 4 connectors and a record switch linkage).

3.7. Meter Ass'y

Refer to Fig. 3.2.

(1) Remove Front Panel Ass'y referring to item 3.4.
(2) Remove F10 (Meter Ass'y) by releasing self-interlocking pins of the Meter Ass'y.

3.8. Lamp P.C.B. R Ass'y and Lamp P.C.B. L Ass'y

Refer to Fig. 3.2.

(1) Remove Meter Ass'y referring to item 3.7.
(2) Remove F11 (Lamp P.C.B. R Ass'y) and F12 (Lamp P.C.B. L Ass'y) by releasing the self-interlocking pins.



Fig. 3.2

3.9. Main P.C.B. Ass'y

Refer to Fig. 3.3.

(1) Refer to Fig. 3.2. Remove Front Panel Ass'y referring to item 3.4.
(2) Remove 4 connectors and the wires connected by wrapping from the F05 (Main P.C.B. Ass'y).
(3) Remove F01, F02, F03, F04 and the Record Switch Linkage from the Wire Holder assembled with Record Switch, then disassemble F05 (Main P.C.B. Ass'y).

3.10. Control Switch Holder Ass'y

Refer to Fig. 3.3.

(1) Refer to Fig. 3.2. Remove Meter Ass'y referring to item 3.7.
(2) Remove F06, then disassemble F07 (Control Switch Holder Ass'y).

3.11. Switch P.C.B. Ass'y

Refer to Fig. 3.3.

(1) Refer to Fig. 3.2. Remove Front Panel Ass'y referring to item 3.4.
(2) Remove F08, then disassemble F09 (Switch P.C.B. Ass'y).

3.12. Volume P.C.B. Ass'y and Control Switch P.C.B. Ass'y

Refer to Fig. 3.3.

(1) Remove Control Switch Holder Ass'y referring to item 3.10.
(2) Remove F10, then disassemble F11 (Volume P.C.B. Ass'y).
(3) Remove F12, then disassemble F13 (Control Button Spring).
(4) Remove F14 (Control Button Shaft), then disassemble F15 (Control Buttons).
(5) Remove F16, then disassemble F17 (Control Switch P.C.B. Ass'y).

3.13. Rear Panel Ass'y, Power Transformer and Power Switch

Refer to Fig. 3.4.

(1) Refer to Fig. 3.1. Remove Top Cover Ass'y and Bottom Cover Ass'y referring to items 3.2 and 3.3.
(2) Remove F01, F02 and F03, then disassemble F04 (Rear Panel Ass'y).
(3) Remove F05 and F06, then disassemble F07 (Power Transformer).
(4) Remove Power Switch Joint Bar by releasing the self-interlocking pin of the Power Switch Joint Bar from Power Switch and F08, then disassemble F09 (Power Switch Holder Ass'y).
(5) Remove F10, then disassemble F11 (Power Switch).



Fig. 3 3

3.14. Cassette Case Ass'y and Cover Plate Ass'y

Refer to Fig. 3.5.

(1) Refer to Fig. 3.2. Remove Mechanism Ass'y referring to item 3.6.
(2) Press the Eject Button to open the Cassette Case Ass'y.
(3) Remove F01, then disassemble the piston of the Pneumatic Damper Ass'y.
(4) Remove F02 and F03 (Cassette Case Holder L Ass'y), then disassemble F04 (Cassette Case Ass'y).
(5) Remove F05, then disassemble F06 (Cover Plate Ass'y).

3.15. Tape Counter Ass'y

Refer to Fig. 3.5.

(1) Refer to Fig. 3.2. Remove Meter Ass'y referring to item 3.7.
(2) Remove F07, then disassemble F08 (Tape Counter Ass'y).



Fig. 3.4



Fig. 3.5

3.16. Capstan Motor Ass'y and Flywheel Ass'y

Refer to Fig. 3.6.

(1) Refer to Fig. 3.2. Remove Mechanism Ass'y referring to item 3.6.
(2) Remove F01 and F02, then disassemble F03 (Flywheel Holder Ass'y) and F08 (Capstan Belt).
(3) Remove F04, then disassemble F05 (Capstan Motor Ass'y).
(4) Remove F06, then disassemble F07 (Control P.C.B. Ass'y).
(5) Remove F09 (Supply Flywheel Ass'y), then disassemble F10 (Take-up Flywheel Ass'y).
(6) After removing both Flywheel Assemblies, disassemble F11 (Thrust Washer 3 mm), F12 (Thrust Washer 2.6 mm), F13 (Flange Thrust Caps) and F14 (Thrust Springs).



Fig. 3.6

3.17. Sub Mechanism Chassis Ass'y

Refer to Fig. 3.7.

(1) Refer to Fig. 3.6. Remove Flywheel Assemblies referring to item 3.16.
(2) Remove F01 and F02, then disassemble F03 (Sub Mechanism Chassis Ass'y).

3.18. Control Motor Ass'y and Reel Motor Ass'y

Refer to Fig. 3.7.

(1) Remove Sub Mechanism Chassis Ass'y referring to item 3.17.
(2) Remove F04, then disassemble F05 (Control Motor Ass'y).
(3) Remove F06, then disassemble F07 (Reel Motor Ass'y).

3.19. Cam Control Volume

Refer to Fig. 3.7.

(1) Remove Sub Mechanism Chassis Ass'y referring to item 3.17.
(2) Remove F08, then disassemble F09 (Volume Coupler).
(3) Remove F10, then disassemble F11 (Cam Control Volume).

3.20. Reel Hub Ass'y and Idler Ass'y

Refer to Fig. 3.7.

(1) Remove Sub Mechanism Chassis Ass'y referring to item 3.17.
(2) Remove F12 (Reel Hub Heads), then disassemble F13 (Reel Hub B Assemblies), F14 (Reel Hub Take-up Ass'y), F15 (Reel Hub Supply Ass'y), F16 (Back Tension Ass'y) and F17 (Back Tension Spring).
(3) Remove F18, then disassemble F19 (Idler Ass'y).

3.21. Cam Drive Gear and Control Cam

Refer to Fig. 3.7.

(1) Remove Sub Mechanism Chassis Ass'y referring to item 3.17.
(2) Remove F20, then disassemble F21 (Cam Drive Gear).
(3) Remove F22, then disassemble F23 (Counter-Load Arm Ass'y).
(4) Remove F24, then disassemble F25 (Control Cam).

3.22. Head Mount Base Ass'y

Refer to Fig. 3.8.

(1) Refer to Fig. 3.5. Remove Cassette Case Ass'y referring to item 3.14.
(2) Remove F01, then disassemble F02 (Head Mount Base Ass'y).

3.23. Pressure Roller Ass'y and Erase Head

Refer to Fig. 3.8.

(1) Remove Head Mount Base Ass'y referring to item 3.22.
(2) Remove F03 and a washer, then disassemble F04 (Supply Pressure Roller Ass'y).
(3) Remove F05, then disassemble F06 (Erase Head).
(4) Remove F07 and a washer, then disassemble F08 (Take-up Pressure Roller Ass'y).

3.24. Record/Playback Head Ass'y

Refer to Fig. 3.8.

(1) Remove Head Mount Base Ass'y referring to item 3.22.
(2) Turn F09 by 90° by pushing it, then disassemble F10 (Record/Playback Head Ass'y).



Fig. 3.7



Fig. 3.8

4. MEASUREMENT INSTRUMENTS

(1) Audio Generator (20 Hz – 200 kHz)
(2) AC Millivolt Meter (with dB measures)
(3) Oscilloscope (DC – 5 MHz)
(4) Distortion Meter
(5) Speed & Wow/Flutter Meter
(6) Frequency Counter (DC – 1 MHz)
(7) Ohm Meter
(8) DC Volt Meter
(9) AC Volt Meter
(10) Torque Gauge (DA09013A)
(11) 15 kHz Azimuth Tape (DA09004A)
(12) 3 kHz Speed & Wow/Flutter Tape (DA09006A)
(13) 1 kHz Track Alignment Tape (DA09007A)
(14) 400 Hz Level Tape (DA09005A)
(15) 20 kHz PB Frequency Response Tape (DA09001A)
(16) 15 kHz PB Frequency Response Tape (DA09002A)
(17) 10 kHz PB Frequency Response Tape (DA09003A)
(18) Reference EXII Tape (DA09021A)
(19) Reference SX Tape (DA09025A)
(20) Reference ZX Tape (DA09037A)
(21) Tilt Check Gauge M-9036 (DA09036A)
(22) Stroke Check Gauge M-9038 (DA09038A)
(23) EH Tilt Check Gauge M-9040 (DA09040A)
(24) EH Stroke Check Gauge M-9042 (DA09042A)
(25) EH Stroke Check Gauge M-9051 (DA09051A)
(26) Audio Analyzer T-100
(including Distortion, Wow/Flutter, Speed, Oscillator and dB meter)

Notes: 1. (10) – (26) are the products of Nakamichi Corporation.
2. EH Stroke Check Gauge M-9042 (DA09042A) should be used for the Models from serial Nos. A304.501001 to A304.516073, and EH Stroke Check Gauge M-9051 (DA09051A) is for the Models bearing serial Nos. A304.516074 and greater.

5. MECHANICAL ADJUSTMENTS

5.1. Mechanism Control Cam Adjustment

Before Adjustment, disassemble the Front Panel Ass'y then remove the Cover Plate Ass'y, referring to items 3.4 and 3.14.

(1) Offset Adjustment of Control Motor Driver

(a) Refer to Figs. 5.1 and 5.2.
Adjust VR602 and VR603 on the Control P.C.B. to locate approximately at the middle of the variable range. Then turn ON the Power Switch.
VR602 (for Cam position stop)
VR603 (for Cam position play)

(b) Press the Stop Switch to set the N-480 in stop mode. Adjust VR602 (for stop) so that the "S" mark on the Cam corresponds to the pointer on the mechanism chassis.

(c) Press the Play Switch to set the N-480 in playback mode.
(Cam will rotate, and the position marked with "PY" comes to the pointer.) Adjust VR603 (for play) so that the "PY" mark on the Cam corresponds to the pointer.

(d) Repeat above (b) and (c) 2 – 3 times so that the "S" and "PY" marks on the Cam correspond to the pointer accurately in stop and playback modes respectively.
(This adjustment is required because the position adjusted by one volume will be slightly changed when the other volume is adjusted.)

(e) Set the N-480 in FF, pause, or record mode by pressing each switch and check to insure that the pointer is in a range of "F", "PS", or "R" mark respectively.

(f) If out of the range, precise adjustment for each position according to "(2) Offset Fine Adjustment of Control Motor Driver" will be required.

(2) Offset Fine Adjustment of Control Motor Driver

Adjust only if a satisfactory result is not obtained in "(1) Offset Adjustment of Control Motor Driver". This adjustment is made by changing the value of the fixed resistors on the Main P.C.B.

Note: The value of voltage is typical value.



Fig. 5.1



Fig. 5.2

(a) Observation Point of Reference Voltage

Observe the each voltage at the sliding contact of the Cam Control Volume VR601 (10 kΩ) in stop, fast (FF or REW), pause, record and playback modes.

Note: When Record and Play Switches are pressed to set N-480 in record mode, the Cam is first set to the record position in a short period of time then stays at the play position.
Therefore to keep the Cam at the record position, following procedure is required:
Short the both leads of capacitor C406 (2.2 μF) on the Main P.C.B. with a jumper wire, then press the Record and Play Switches.

(b) Reference Voltage

Reference voltage at the sliding contact of VR601 (Cam Control Volume) in each mode is as follows:

Mode	Reference Voltage (Typical Value)
Record	16 V
	1 V +0.4 V −0.2 V
Stop	15 V
	1.5 V ± 0.25 V
Fast (FF/REW)	13.5 V
Pause	10 V
	2.5 V ± 0.4 V
Play	7.5 V

(c) Resistors for Adjustment

Mode	Ref. No.	Typical Value
Stop	R415, R416	9.1 kΩ(F),15 kΩ(F)
Fast (FF/REW)	R414	56 kΩ (F)
Pause	R454	680 kΩ
Play	R453	120 kΩ
Record	R419	150 kΩ

(d) Adjustment Procedures

1) Press the Stop Switch to set the N-480 in stop mode. Adjust the value of R415 and R416 to obtain 15 V (±0.6 V) at the sliding contact of VR601.
Note: When R415 and R416 are adjusted, the reference voltage in Fast (FF or REW) mode is changed. Therefore, re-check of the reference voltage in Fast (FF or REW) mode is required. If the reference voltage is out of the range, re-adjustment of R414 according to next step 2) is necessary.

2) Set the N-480 in FF mode, then adjust the value of R414 so that the voltage of VR601 will become lower by 1.5 V (±0.25 V) than in stop mode.

3) Press the Pause Switch to set the N-480 in pause mode.
Adjust the value of R454 to obtain 10 V (+0.4, -0.15 V) at the sliding contact of VR601.

4) Set the N-480 in playback mode, then adjust the value of R453 so that the voltage of VR601 will be-

come lower by 2.5 V (±0.4 V) than in pause mode.

5) Short the both leads of capacitor C406 with a jumper wire.
Set the N-480 in record mode, then adjust the value of R419 so that the voltage of VR601 will become higher by 1 V (+0.4, -0.2 V) than in stop mode.
Note: Remove the short of C406 after completion of adjustment.

(3) Cam Timing Adjustment

(a) Remove the wires from the Control Motor terminals to set the motor open.

(b) Without loading a cassette tape and with pressing the record protecting switch with your finger tip, press the Record and Play Switches to set the N-480 in record mode.

(c) Turn the Cam and bring the "PY" mark toward the pointer by hand.
Reel Motor will rotate before the "PY" mark reaches the pointer.
Adjust the value of R436 so that the voltage at the sliding contact of VR601 becomes 9.7 V (±0.3 V) when Reel Motor starts rotation.

(d) Observe the mute signal at the Q416 collector.
Turn the Cam referring to above step (c) and check to insure that the voltage at the sliding contact of VR601 is 9.5 V (±0.3 V) when mute is released (mute signal changes from H to L).
(This voltage is determined by the adjustment of R436 in above step (c).)

(e) Observe the (Play + Pause)—Position signal at the Q411 collector.
Turn the Cam referring to above step (c) and adjust the value of R432 to obtain 11.2 V (±0.4 V) at the sliding contact of VR601 when (Play + Pause)—Position signal changes from L to H (bias oscillation will begin).

(f) Upon completion of above adjustment, re-connect wires to the motor terminals.

5.2. Tape Speed Adjustment

(1) Remove the Top Cover.

(2) Connect a Frequency Counter to the Output Jack.

(3) Load a 3 kHz Speed Wow/Flutter Tape (DA09006A) and play it back.

(4) Referring to Fig. 5.3, adjust the Tape Speed Adjustment Volume (VR501) incorporated in the Capstan Motor to obtain 3,000 Hz on the Frequency Counter.
CCW: Motor drives slowly.
CW: Motor drives fast.



Fig. 5.3

5.3. Record/Playback Head Tilt Adjustment

On items 5.3 — 5.7, please refer to Fig. 5.4 flow chart.
Refer to Figs. 5.5 and 5.6.

(1) Load a Tilt Check Gauge M-9036 (DA09036A) in the N-480.

(2) Clip the grounding terminal of the Tilt Check Gauge with one end of the cord with clip, and the other end to the chassis of the N-480.

(3) Remove Height Gear.

(4) Set the N-480 in play mode. Check to insure whether the Beacon "Upper" or "Lower" is illuminating. In order not to give damages onto the record/playback head surface, push the slide knob of the gauge to the direction of an arrow mark, then return it to the original place to be in contact with record/playback head surface after play mode is securely locked.

(5) Check to insure freedom from contact between the gauge and pad lifter.

(6) Beacon "Lower" will light on when height adjustment screw turned clockwise but "Upper" when counterclockwise. Adjust so that both "Upper" and "Lower" will light on even when you move the slide knob to the direction of an arrow mark and then return it to the original place.

(7) Set the N-480 in stop mode and fit the serrated Height Gear. Then set the N-480 again in play mode and insure 2 Beacons "Upper" and "Lower" are illuminating.
If not, (3) through (6) will have to be repeated till satisfactory results are obtained.


START
Record/Playback Head Tilt Adjustment
Tilt Check Gauge M-9036
Head Base Stroke Adjustment in Play Mode and Cue Mode
Stroke Check Gauge M-9038
Remove Head Mount Base Ass'y
Tape Guides and Erase Head Stroke Adjustment
EH Stroke Check Gauge M-9042 or M-9051
Erase Head Height and Tilt Adjustment
EH Tilt Check Gauge M-9040
Assemble Head Mount Base Ass'y
NG
Record/Playback Head Tilt Check
Tilt Check Gauge M-9036
OK
NG
Head Base Stroke Check
Stroke Check Gauge M-9038
OK
Record/Playback Head Height Adjustment and Azimuth Alignment
END

Fig. 5.4



Fig. 5.5



Fig. 5.6

5.4. Head Base Stroke Adjustment

Refer to Fig. 5.7.

Note: Before you conduct "Head Base Stroke Adjustment", adjust with a "Tilt Check Gauge" to insure freedom from tilt on the record/playback head.

(1) Load a Stroke Check Gauge M-9038 (DA09038A) in the N-480.

(2) Set the N-480 in play mode.

(3) Check to insure whether the "P" pointer on the Stroke Indicator locates between 2 lines as marked on the Stroke Check Plate.

(4) If the record/playback head stroke is noted to be misaligned, adjustment can be made by moving the stroke adjuster assembled in the head base assembly (either forwardly or backwardly).



Fig. 5.7

5.5. Tape Guides Adjustment and Erase Head Stroke Adjustment

Remove Head Mount Base Ass'y. Refer to Figs. 5.8 and 5.9.

(1) Supply Tape Guide Height Adjustment

(a) Load an EH Stroke Check Gauge M-9042/M-9051 in the N-480.
(b) Set the N-480 in play mode.
(c) Slide the Supply Tape Guide Check Bar down against the supply tape guide, thus check can be made on supply tape guide height.
(d) If the supply tape guide is misaligned, the Supply Tape Guide Check Bar will not come into the supply tape guide. If such is noted, turn to adjust the height adjustment nut A till the Supply Tape Guide Check Bar is accepted by the supply tape guide.
(e) If the above are insured, set the N-480 in pause mode, then in play mode to see whether adjustments are appropriately made. If not, (b) through (e) will have to be repeated till satisfactory results are obtained.



Fig. 5.8

(2) Take-up Tape Guide Height Adjustment

(a) Load an EH Stroke Check Gauge M-9042/M-9051 in the N-480.
(b) Set the N-480 in play mode.
(c) Slide the Take-up Tape Guide Check Bar down against the take-up tape guide, thus check can be made on take-up tape guide height.
(d) If the take-up tape guide is misaligned, the Take-up Tape Guide Check Bar will not come into the take-up tape guide. If such is noted, turn to adjust the height adjustment nut B till the Take-up Tape Guide Check Bar is accepted by the take-up tape guide.
(e) If the above are insured, set the N-480 in pause mode, then in play mode to see whether adjustments are appropriately made. If not, (b) through (e) will have to be repeated till satisfactory results are obtained.

(3) Erase Head Stroke Adjustment

(a) Load an EH Stroke Check Gauge M-9042/M-9051 in the N-480.
(b) Set the N-480 in play mode, thus check can be made on erase head stroke through the EH Stroke Indicator.
(c) Check to insure whether the erase head surface is aligned with red line on the EH Stroke Indicator. If not, adjust the erase head stroke by loosening 2 screws that assembled erase head and erase head plate.
(d) After completion of adjustment, 2 pcs. of screws shall be locked with lock tight paint.

Note: EH Stroke Check Gauge M-9042 (DA09042A) should be used for the Models from Serial Nos. A304.501001 to A304.516073, and EH Stroke Check Gauge M-9051 (DA09051A) is for the Models bearing Serial Nos. A304.516074 and greater.



Fig. 5.9

5.6. Erase Head Height and Tilt Adjustment

Refer to Figs. 5.10 and 5.11.

(1) Remove Head Mount Base Ass'y.
(2) Load an EH Tilt Check Gauge M-9040 (DA09040A) in the N-480.
(3) Set the N-480 in stop mode.
(4) Check to insure whether one of the 3 Beacons is illuminating. Look down the mirror as shown by an arrow mark and slowly turn the Screw "Height" counterclockwise (or clockwise) so that the two horizontal lines of the mirror will become superposed on the line (in different color) of the erase head, and check to insure whether Beacon "1" is illuminating.
(5) Turn Screw "Tilt" counterclockwise (or clockwise) to light on Beacon "2". Excessive turning will cause the Beacon "1" to light off.
Adjustments of Screw "Tilt" will therefore be conducted till both of the Beacons "1" and "2" illuminate.
(6) Turn Screw "Azimuth" counterclockwise (or clockwise) to light on Beacon "3". Excessive turning will cause either Beacon "1" or "2" to light off, and therefore adjust with Screw "Azimuth" until all of the 3 Beacons "1", "2" and "3" illuminate.
(7) Check to insure whether the horizontal line on the mirror corresponds to that on the erase head. If not, (4) through (7) will have to be repeated till satisfactory results are obtained.
(8) After completion of adjustment, 3 pcs. of screws shall be locked with lock tight paint.

Note: Before use of this gauge, check to insure freedom from dust or dirts, or overflow in the groove of the erase head surface.



Fig. 5.10



Fig. 5.11

5.7. Record/Playback Head Height Adjustment and Azimuth Alignment

Refer to Fig. 5.12.

(1) Connect a VTVM to the Output Jacks.
(2) Load a 1 kHz Track Alignment Tape (DA09007A) in the N-480.
(3) Set the N-480 in play mode.
(4) Turn the Height Gear until the output of both channels becomes minimum.
(5) Load a 15 kHz Azimuth Tape (DA09004A) in the N-480.
(6) Set the N-480 in play mode.
(7) Turn the Azimuth Alignment Screw until the output of both channels becomes maximum.
(8) Repeat (2) through (7) 1 – 2 times.



Fig. 5.12

5.8. Tape Travelling Adjustment

The adjustment shall be made with a modified version of the current type EXII C-90 tape as shown in the Fig. 5.13 (error will be made if a current type Tape Travelling Cassette (DA09011A) should be used for this purpose). While modifying an EXII C-90 tape, the tape guides in the cassette housing shall be kept protected to avoid tilt.

Check shall be made in the following procedures:

(1) An EXII C-90 tape thus modified shall be loaded onto the N-480.

(2) Release the back-tension (rotate the supply reel and feed out some length of tape) and set the N-480 in play mode.

(3) In this juncture, check to insure whether the tape is freedom from waving or slippage from the both of tape guides.

(4) When the modified EXII C-90 tape is played back, check to insure whether the tape is freedom from waving from head surface or at pressure rollers.

(5) If either of waving or slippage from the tape guides should be noted, adjustments of "5.3. Record/Playback Head Tilt Adjustment", "5.4. Head Base Stroke Adjustment", "5.5. Tape Guides Adjustment and Erase Head Stroke Adjustment", "5.6. Erase Head Height and Tilt Adjustment", "5.7. Record/Playback Head Height Adjustment and Azimuth Alignment", etc. will be required.

As a case may be, the said waving or slippage may have been caused from defective Supply Pressure Roller Ass'y or Take-up Pressure Roller Ass'y without parallel contact with Capstans.

If such are noted, the Pressure Roller Assemblies will have to be replaced. Further, excessively weak take-up torque or strong take-up torque may cause defective tape travelling.

The N-480 is intended to be adjustment-free Model. However if the similar matters as above should be noted, please replace the Reel Hub Take-up Ass'y to obtain appropriate take-up torque.



Fig. 5.13

5.9. Record Switch Linkage Adjustment

(1) Set the N-480 in stop mode.

(2) Loosen the screw of the Record Spring Holder, and shift the Record Spring Holder in order to remove the looseness of the Linkage Wire as shown in Fig. 5.14.1. Then tighten the screws for fixing the Record Spring Holder. (In this case, the Record Switch should be positioned at play side. If on the record position, it will be defective.)

(3) Set the N-480 in record and pause mode.
Check to insure that the gap between the top of the wire and the Record Spring Holder is approx. 1 mm as shown in Fig. 5.14.2.
(Check that the Record Switch is in record position.)

(4) Upon completion of the above adjustments, apply a quantity of lock tight paint.



Fig. 5.14.1



Fig. 5.14.2

5.10. Flywheel Holder Adjustment

(1) Refer to Fig. 5.15.
Tighten the Thrust Screws until the gap between the Flywheel Assemblies and Thrust Screws becomes minimized when both of the Capstan Shafts are moved backwardly and forwardly (the Thrust Springs between the Capstan Flanges and Flywheel Thrust Caps are in a flat state).
Excessive tightening of the Thrust Screws however will give damages on the Flywheel Assemblies, to which careful attention is invited.

(2) Return the Thrust Screws by 1/2 turn.

(3) Fixing the Thrust Screws with a screwdriver, lock the Lock Nut.

(4) Apply a quantity of lock tight paint to the Thrust Screws.



Fig. 5.15

5.11. Eject Wire Adjustment

(1) Referring to Fig. 5.16.1, insert a 1.5 mm spacer between the Eject Arm and Eject Stopper by turning the Eject Arm in the illustrated direction, then set the N-480 in playback mode.

(2) With pushing the Eject Arm by hand, loosen the screw and then pull the Eject Wire in the direction of the arrow until it stops as shown in Fig. 5.16.2.

(3) Tighten the screw, then apply a quantity of lock tight paint.



Fig. 5.16.1

5.12. Lubrication

N-480 is a lubrication-free cassette deck except when parts are replaced. Apply the following lubricant for each replaced part:

(1) LAUNA #100
Capstan Shaft
Pressure Roller Shaft
Thrust Cap

(2) FLOIL GB-TS-1
Reel Hub Shaft
Thrust portion on the Capstan Shaft
FLOIL GB-TS-1, made by Kanto Chemicals Co., Ltd., in Japan.
We suggest you use the above or equivalent type. If unavailable please contact Kanto Chemicals Co., Ltd., 2-7 Kanda Suda-cho Chiyoda-ku, Tokyo 101 Japan.

(3) Silicon Oil #3000 CST
Air Damper Piston
Note: Excessive lubrication may cause defective damper action as the 0.2ϕ hole at the end of the cylinder may be filled with oil.



Fig. 5.16.2

5. PARTS LOCATION FOR ELECTRICAL ADJUSTMENT



Fig. 6

7. ELECTRICAL ADJUSTMENTS AND MEASUREMENTS

7.1. Adjustment and Measurement Instructions

Note: Electrical adjustment should be performed after mechanical adjustment is completed.

STEP	ITEM	SIGNAL SOURCE	OUTPUT CONNECTION	MODE	ADJUSTMENT	REMARKS
1	Tape Speed	3 kHz Speed and Wow/Flutter Tape (DA09006A)	Frequency Counter to OUTPUT Jacks	Playback Eq. SW — 70 μs	Capstan Motor Governor P.C.B. VR501	Adjust VR501 to obtain 3 kHz ± 0.5%. (VR501 is incorporated in the capstan motor.)
2	Meter Level	400 Hz to INPUT Jacks	VTVM to TP101, TP201 on the Main P.C.B.	Record, Pause	Main P.C.B. VR105, VR205	1. Set the input level controls to maximum. 2. Adjust the oscillator output to obtain 100 mV at TP101 (TP201), then adjust VR105 (VR205) to obtain 0 dB on the level meters.
3	MPX Filter	19 kHz ± 100 Hz to INPUT Jacks	VTVM to OUTPUT Jacks	Record, Pause MPX SW — OUT/IN	Main P.C.B. L103, L203	1. Adjust input level controls to obtain 600 mV on the VTVM. 2. Set the MPX Switch to IN position, then adjust L103 (L203) to obtain minimum reading on the VTVM (minimum reading will be less than —30 dB).
4	Record/Playback Head Track Alignment	1 kHz Track Alignment Tape (DA09007A)	Same as above	Playback MPX SW — OUT Eq. SW — 70 μs Dolby NR SW — OUT	Record/Playback Head Height Adjustment Screw	Adjust the Record/Playback Head Height Adj. Screw to obtain minimum reading of both L and R channels on the VTVM. See "Record/Playback Head Height Adjustment and Azimuth Alignment" in item 5.7.
5	Record/Playback Head Azimuth Alignment	15 kHz Azimuth Tape (DA09004A)	Same as above	Same as above	Record / Playback Head Azimuth Alignment Screw	Adjust the Record/Playback Head Azimuth Alignment Screw to obtain maximum reading of both L and R channels on the VTVM. See "Record/Playback Head Height Adjustment and Azimuth Alignment" in item 5.7. Note: Repeat steps 4 and 5 one or two times to obtain optimum performance.
6	Playback Level	400 Hz Level Tape (DA09005A)	VTVM to TP101, TP201	Same as above	Main P.C.B. VR101, VR201	Adjust VR101 (VR201) to obtain 100 mV on the VTVM or 0 dB on the level meters.
7	Playback Frequency Response	400 Hz Level Tape (DA09005A) 10 kHz PB Frequency Tape (DA09003A) 15 kHz PB Frequency Tape (DA09002A) 20 kHz PB Frequency Tape (DA09001A)	VTVM to OUTPUT Jacks	Same as above	Main P.C.B. R112, R212	1. Load the 400 Hz level tape and play it back. 2. Load the 10 kHz, 15 kHz and 20 kHz PB Frequency Response Tapes and adjust the record/playback head azimuth to give maximum levels on the VTVM with each tape. Short R112 (R212) to obtain the following levels against 400 Hz level tape. Refer to Fig. 7.3. 10 kHz (—20 dB) —2 dB to + 2 dB 15 kHz (—20 dB) —2 dB to + 3 dB 20 kHz (—20 dB) —2 dB to + 4 dB 3. Conduct step 5 "Record/Playback Head Azimuth Alignment 4. If above is not sufficient, refer to "Playback Frequency Response Adjustment" in item 7.2.



Fig. 7.1
2. Meter Level



Fig. 7.2
3. MPX Filter



Fig. 7.3
6. Playback Level
7. Playback Frequency Response

STEP	ITEM	SIGNAL SOURCE	OUTPUT CONNECTION	MODE	ADJUSTMENT	REMARKS
8	Bias Oscillation Frequency and Erase Current	External 0.1 Ω Resistor in series to Erase Head	VTVM and Frequency Counter across the 0.1 Ω Resistor	Record, Pause ZX SW — IN Eq. SW — 70 μs Dolby NR SW — OUT MPX SW — OUT	Main P.C.B. T301 R310, R311	1. Adjust T301 to obtain 105 kHz on the frequency counter. 2. Check the erase current by the VTVM. Erase current will be in a range of 310 mA to 400 mA (typically approx. 350 mA). If erase current is not sufficient, increase it by shorting R310 or R311. 3. After completion of the erase current adjustment, re-check the bias oscillation frequency.
9	Record Amplifier Equalizer	21 kHz (–20 dB) to INPUT Jacks	VTVM to TP102, TP202	Same as above	Main P.C.B. L104, L204	1. Remove the bias-cut-jumper from the dip side of the Main P.C.B. 2. Adjust L104 (L204) to obtain peak reading at 21 kHz on the VTVM. 3. Re-solder the bias-cut-jumper.
10	Bias Trap	Remove INPUT Signals	Same as above	Same as above	Main P.C.B. L105, L205	Adjust L105 (L205) to obtain maximum reading on the VTVM.
11	Record Level Calibration	400 Hz to INPUT Jacks	VTVM to OUTPUT Jacks	Record and Playback ZX SW — IN/OUT SX/EX SW — SX/EX Eq. SW — 120 μs (EX) 70 μs (SX/ZX) Dolby NR SW — OUT MPX SW — OUT	Main P.C.B. VR102, VR202 VR103, VR203 VR104, VR204	1. Set the input level controls to obtain 0 dB on the level meters. 2. Record signals on the reference EXII (DA09021A), reference SX (DA09025A) or reference ZX (DA09037A), then play it back. 3. Repeating 2 as above, adjust VR104 (VR204) (for EXII), VR103 (VR203) (for SX) and VR102 (VR202) (for ZX) to obtain 0 dB on the level meters in playback mode.
12	Recording Bias Current and Overall Frequency Response	400 Hz to INPUT Jacks and 20 Hz to 18 kHz (–20 dB) to INPUT Jacks	VTVM and Distortion Meter to OUTPUT Jacks	Record and Playback ZX SW — IN/OUT SX/EX SW — SX/EX Eq. SW — 120 μs (EX) 70 μs (SX/ZX) Dolby NR SW — OUT MPX SW — OUT	Switch P.C.B. VR701, VR801 VR702, VR802 VR703, VR803	1. Feed in 400 Hz and adjust input level controls to obtain 0 dB on the level meters. 2. Record signals on the reference EXII tape (DA09021A), reference SX tape (DA09025A), or reference ZX tape (DA09037A). 3. Repeating 2 as above, play back the tape and adjust VR701 (VR801) (for EXII), VR702 (VR802) (for SX) or VR703 (VR803) (for ZX) to obtain maximum reading on the VTVM. 4. Conduct step 11 "Record Level Calibration". 5. Feed in 10 kHz (–20 dB) then record and play it back. Adjust VR104 (VR204) (for EXII), VR103 (VR203) (for SX) or VR102 (VR202) (for ZX) on the Main P.C.B. Ass'y to obtain approximately –20 dB on the VTVM. Feed in 18 kHz (–20 dB) then record and play it back. Adjust recording peaking coil L104 (L204) to obtain approximately –20 dB on the VTVM (refer to step 9 "Record Amplifier Equalizer"). 6. Conduct step 11 "Record Level Calibration". 7. Feed in 400 Hz and adjust the input level controls to obtain 0 dB on the level meters, then record and play it back and check to insure whether the Total Harmonic Distortion (T.H.D.) is less than 1.0% for EXII, 1.2% for SX and 1.0% for ZX. Feed in 20 Hz to 18 kHz (–20 dB) then record and play it back, and check to insure whether the output levels are within –20 dB ± 4 dB. 8. If T.H.D. exceeds 1.2%, the following adjustments are required: a. Repeat 5 as above. Adjust bias calibration semi-fixed volumes and peaking coils to obtain –22 dB instead of –20 dB on the VTVM. b. Perform step 11 "Record Level Calibration". c. Repeat 7 as above. d. If above is not sufficient, precise re-adjustment of step 7 "Playback Frequency Response", replacement of Record/Playback Head or check of item 5.8 "Tape Travelling Adjustment" will be required. 9. Conduct step 11 "Record Level Calibration".

STEP	ITEM	SIGNAL SOURCE	OUTPUT CONNECTION	MODE	ADJUSTMENT	REMARKS
13	Crosstalk	1 kHz to INPUT Jacks	1 kHz Band Pass Filter and VTVM to OUTPUT Jacks	Record and Playback ZX SW — OUT SX/EX SW – SX Eq. SW — 70 μs Dolby NR SW — OUT MPX SW — IN		1. Erase the tape with bulk eraser. 2. Adjust the input level controls to obtain 0 dB on the level meters, and record the signals on the reference SX tape (DA09025A). 3. Turn the cassette tape the other way round and play it back. 4. Measure the difference between 2 and 3.
14	Channel Separation	1 kHz to INPUT Jacks	Same as above	Same as above		1. Erase the tape with bulk eraser. 2. Adjust L ch (R ch) input level control to obtain 0 dB on the level meter, and close R ch (L ch) input level control. 3. Record and play it back, then meausre the R ch (L ch) level.
15	Erasure	100 Hz to INPUT Jacks	100 Hz Band Pass Filter and VTVM to OUTPUT Jacks	Record and Playback ZX SW — IN Eq. SW — 70 μs Dolby NR SW — OUT MPX SW — IN		1. Erase the tape with bulk eraser. 2. Adjust input level controls to obtain 0 dB on the level meters, and record the signals on the reference ZX tape (DA09037A). 3. Rewind the tape, close input level controls, and then record again. 4. Rewind the tape, play it back, and then measure the difference between 2 and 3.
16	Signal to Noise Ratio	400 Hz to INPUT Jacks	IHF-A Curve Filter, Distortion Meter and VTVM to OUTPUT Jacks	Record and Playback ZX SW — IN Eq. SW — 70 μs Dolby NR SW — IN MPX SW — IN		1. Feed in 400 Hz and record, and play it back. 2. Adjust the input level controls to obtain 3% total harmonic distortion in playback mode. 3. Close the input level controls then record. 4. After rewound, play back and check the output level difference between 2 and 3. Note: The filter of IHF-A curve shall be used in the measurments.
17	Total Harmonic Distortion	400 Hz to Input Jacks	Distortion Meter to OUTPUT Jacks	Record and Playback ZX SW — IN/OUT SX/EX SW – SX/EX Eq. SW — 120 μs (EX) 70 μs (SX, ZX) Dolby NR SW — OUT MPX SW — IN		1. Adjust the input level controls to obtain 0 dB on the level meters. 2. Record and play it back. 3. Read the distortion meter and check to insure that the distortion is as follows: EXII . . . . . 1.0% or less SX . . . . . 1.2% or less ZX . . . . . 1.0% or less
18	Wow/Flutter	3 kHz Speed and Wow/Flutter Tape (DA09006A)	Wow/Flutter Meter to OUTPUT Jacks	Playback Eq. SW — 70 μs		Playback and read the wow/flutter meter.



Fig. 7.4 8. Bias Oscillation Frequency and Erase Current



Fig. 7.5 9. Record Amplifier Equalizer
10. Bias Trap
11. Record Level Calibration



Fig. 7.6 12. Record Bias Current and Overall Frequency Response

7.2. Playback Frequency Response Adjustment

Fig. 7.7 shows the playback equalization curve for the N-480, and Fig. 7.8 is the circuit for adjustment.

(1) Level Adjustment (for middle frequency response)

This adjustment will be required when playback level is not sufficient at 10 kHz PB Frequency Response Tape (refer to step 7 in "7.1. Adjustment and Measurement Instructions").

Playback equalization level can be varied by the modification of R108 (R208) and R109 (R209).

Following are the details for level modification:

Approx. +1 dB	R108 (R208):	2 k
	R109 (R209):	2.4 k
0 dB	R108 (R208):	1.8 k
	R109 (R209):	2.2 k
Approx. -1 dB	R108 (R208):	1.6 k
	R109 (R209):	2 k

(2) Peaking Adjustment (for high frequency response)

This adjustment will be required when playback level is not sufficient at 20 kHz PB Frequency Response Tape (refer to step 7 "7.1. Adjustment and Measurement Instructions").

Peaking portion compensates the gap loss of the playback head. Peaking level is varied by the short circuit of R112 (R212) or R111 (R211) as illustrated in the figure.



Fig. 7.7 Playback Equalization Curve



Fig. 7.8 Playback Amp.

7.3. Check on Dolby NR Circuit

Dolby NR Circuit incorporates a Dolby B-Type NR IC (μA7300PC) which has no adjustment point.

Perform the following checks and make sure that the IC operates accurately i.e., frequency response through IC is accurate.

Signal Source:	5 kHz to INPUT Jacks
Output Connection:	VTVM to the output side of C154 (C254) on the Main P.C.B.
Mode:	Record Pause MPX SW — IN

(1) Remove the Bias-cut Jumper from the dip side of the Main P.C.B.

(2) Connect a VTVM to TP101 (TP201) on the Main P.C.B.
Feed in 5 kHz and adjust the input level so that the VTVM may read 100 mV (0 dB) at each Test Point. Pointer on the meter will indicate 0 dB.

(3) Remove the VTVM from TP101 (TP201) and reconnect it to the output side of C154 (C254).

(4) Decrease the input level (0 dB) by 20 dB or 30 dB. Check to insure that the level at output side of C154 (C254) corresponds to the following with the Dolby NR Switch IN and OUT.

(5) After completion of the adjustment, reconnect the Bias-cut Jumper.

Input Level	Capacitor Output Level		
(f=5 kHz)	Dolby NR OUT	Dolby NR IN	Difference between IN and OUT
−20 dB	−20 dB	−16.8 dB ± 1.5 dB	3.2 dB ± 1.5 dB
−30 dB	−30 dB	−21.8 dB ± 1.5 dB	8.2 dB ± 1.5 dB

8. MOUNTING DIAGRAMS AND PARTS LIST

Note: Mounting diagram shows a dip side view of the printed circuit board.

8.1. Volume P.C.B. Ass'y



Fig. 8.1

8.2. Control Switch P.C.B. Ass'y



Fig. 8.2 Note: Diode is 1SS53 unless otherwise specified.

8.3. Switch P.C.B. Ass'y



Fig. 8.3

8.4. Control P.C.B. Ass'y



Fig. 8.4

8.5. Auto Shut-off P.C.B. Ass'y



Fig. 8.5

Note: Diode is 1SS53 unless otherwise specified.

8.6. Lamp P.C.B. L Ass'y



Fig. 8.6

8.7. Lamp P.C.B. R Ass'y



Fig. 8.7

Schematic Ref. No.	Part No.	Description
	BA04114A	**Volume P.C.B. Ass'y**
	0B07845B	Volume P.C.B.
VR001,002	0B07298A	Slide Volume 50K (A)
	BA04126A	**Control P.C.B. Ass'y**
	0B07849B	Control P.C.B.
VR602,603	0B09059A	Semi-fixed Volume 5K
R606	0B05698A	Carbon Resistor 1.5K ERD-25T J
R607	0B05622A	Carbon Resistor 2.2K ERD-25T J
	BA04127A	**Switch P.C.B. Ass'y**
	0B07846C	Switch P.C.B.
VR701,801	0B07237A	Semi-fixed Volume 50K
VR702,802	0B07261A	Semi-fixed Volume 20K
VR703,803	0B07236A	Semi-fixed Volume 10K
C701, 801	0B09283A	Ceramic Capacitor 220P 50V K
	0B07302A	Push Switch 6-6-4 (1 pce.)
	BA04113A	**Control Switch P.C.B. Ass'y**
	0B07848B	Control Switch P.C.B.
D601	0B06181A	Silicon Diode 1SS53
R608, 609	0B01679A	Carbon Resistor 100 ERD-25T J
C605, 606	0B01405A	Electrolytic Capacitor 1μ 50V
PL601, 602 603	0B08673A	Lamp 24V 20mA
	0B07297A	Control Switch (1 pce.)

Schematic Ref. No.	Part No.	Description
	BA04128A	**Auto Shut-off P.C.B. Ass'y**
	0B07852B	Auto Shut-off P.C.B.
Q449	0B06100A	Transistor 2SC945 (A)
Q450	0B06228A	Photo Transistor PH104
D470	0B06181A	Silicon Diode 1SS53
R602	0B01888A	Carbon Resistor 10K ERD-25T J
R603	0B05671A	Carbon Resistor 2.2M ERD-25T J
R604	0B05615A	Carbon Resistor 22K ERD-25T J
R605	0B01933A	Carbon Resistor 220 ERD-25T J
C453	0B01405A	Electrolytic Capacitor 1μ 50V
PL407	0B08552A	Lamp 12V 25mA
	BA04125A	**Lamp P.C.B. L Ass'y**
	0B07851B	Lamp P.C.B. L
PL001	0B08674A	Lamp 5V 200mA
	BA04124A	**Lamp P.C.B. R Ass'y**
	0B07850B	Lamp P.C.B. R
PL002	0B08674A	Lamp 5V 200mA

8.8. Main P.C.B. Ass'y



Note: Diode is 1SS53 unless otherwise specified.

Fig. 8.8.1 Serial No.: A304.518705 –

Schematic Ref. No.	Part No.	Description
	BA04130A	**Main P.C.B. Ass'y (U.S.A. & Canada)**
	BA04112A	**Main P.C.B. Ass'y (Japan)**
	BA04131A	**Main P.C.B. Ass'y (220V Class 2)**
	BA04132A	**Main P.C.B. Ass'y (UK & Australia)**
	BA04133A	**Main P.C.B. Ass'y (Others)**
		Serial No.: A304.518705 –
	– PB Eq. Amp. –	
Q101, 102	0B06119A	Transistor 2SC1844
201, 202		
ZD301	0B06239A	Zener Diode RD20EB
L101, 201	0B03919B	Inductor 36mH
VR101,201	0B07237A	Semi-fixed Volume 50K
R101, 103	0B01889A	Carbon Resistor 100K ERD-25T J
201, 203		
R102, 202	0B01706A	Carbon Resistor 47 ERD-25T J
R104, 106	0B05509A	Carbon Resistor 33K ERD-25T J
204, 206		
R105, 205	0B09330A	Carbon Resistor 100K ERD-25TS J (Noiseless)
R107, 109	0B05622A	Carbon Resistor 2.2K ERD-25T J
207, 209		
308		
R108, 208	0B05614A	Carbon Resistor 1.8K ERD-25T J
R110, 210	0B05621A	Carbon Resistor 120K ERD-25T J
R111, 211	0B05577A	Carbon Resistor 330 ERD-25T J
R112, 212	0B05794A	Carbon Resistor 680 ERD-25T J
R113, 213	0B05641A	Carbon Resistor 47K ERD-25T J
R166, 266	0B05936A	Carbon Resistor 10 ERD-25T J
C101, 201	0B09137A	Electrolytic Capacitor 22μ 16V (LN)
C102, 202	0B09376A	Electrolytic Capacitor 22μ 25V (LN)
C103, 203	0B09283A	Ceramic Capacitor 220P 50V K
C105, 205	0B05885A	Electrolytic Capacitor 100μ 10V
C106, 206	0B09045A	Mylar Capacitor 0.027μ 50V J
C107, 207	0B01412A	Electrolytic Capacitor 10μ 16V
C108, 208	0B01272A	Electrolytic Capacitor 100μ 25V
C109, 209	0B05653A	Mylar Capacitor 1500P 50V J
	– Dolby NR –	
IC101, 201	0B06175A	IC μA7300PC
L102, 202	0B03919B	Inductor 36mH
L103, 203	0B03563A	19K Coil 23mH
R114, 214	0B01846A	Carbon Resistor 4.7K ERD-25T J
R115, 215	0B01888A	Carbon Resistor 10K ERD-25T J
R116, 216	0B05629A	Carbon Resistor 2.7K ERD-25T J
R117, 217	0B01887A	Carbon Resistor 5.6K ERD-25T J
R118, 119	0B05509A	Carbon Resistor 33K ERD-25T J
218, 219		
R120, 124	0B05620A	Carbon Resistor 270K ERD-25T J
220, 224		
R121, 221	0B09317A	Metal Film Resistor 3.3K SN14K2E F
R122, 222	0B05641A	Carbon Resistor 47K ERD-25T J
R123, 223	0B09271A	Carbon Resistor 6.2K ERD-25T J
R162, 262	0B01857A	Carbon Resistor 1K ERD-25T J
R165, 265	0B09383A	Fail Safe Type Resistor 390 RDF-25S J
R167, 267	0B05776A	Carbon Resistor 1M ERD-25T J
R169, 269	0B05627A	Carbon Resistor 330K ERD-25T J
C110, 210	0B09223A	Electrolytic Capacitor 1μ 50V (LN)
C111, 211	0B01403A	Electrolytic Capacitor 47μ 16V
C112, 212	0B09242A	Mica Capacitor 47P 50V J
C113, 213	0B09262A	PP Capacitor 3000P 50V J

Schematic Ref. No.	Part No.	Description
C114, 214	0B01913A	Mylar Capacitor 1800P 50V J
C115, 116	0B01412A	Electrolytic Capacitor 10μ 16V
117, 123		
215, 216		
217, 223		
C118, 218	0B09191A	PP Capacitor 4700P 100V G
C119, 219	0B01804A	Mylar Capacitor 3900P 50V J
C120, 220	0B09240A	PP Capacitor 0.033μ 100V G
C121, 221	0B01862A	Electrolytic Capacitor 22μ 16V
C122, 222	0B05583A	Mylar Capacitor 0.033μ 50V J
C124, 224	0B01603A	Mylar Capacitor 0.1μ 50V K
C125, 225	0B09327A	Electrolytic Capacitor 0.33μ 50V (LN)
C136, 236	0B05885A	Electrolytic Capacitor 100μ 10V
C137, 237	0B01272A	Electrolytic Capacitor 100μ 25V
	– Rec. Amp. –	
Q103, 203	0B01872A	Transistor 2SC945 (L)
L104, 105	0B00068A	Trap Coil 10.5mH
204, 205		
VR102,103	0B07237A	Semi-fixed Volume 50K
104,202		
203,204		
R127, 129	0B01683A	Carbon Resistor 15K ERD-25T J
209, 210		
ZD101,201	0B06191A	Zener Diode 2.7EB
D104, 105	0B06181A	Silicon Diode 1SS53
204, 205		
VR105,205	0B07237A	Semi-fixed Volume 50K
R154, 159	0B01889A	Carbon Resistor 100K ERD-25T J
254, 259		
R155, 255	0B09318A	Metal Film Resistor 560K SN14K2E F
R157, 158	0B01888A	Carbon Resistor 10K ERD-25T J
257, 258		
R160, 260	0B05691A	Carbon Resistor 390 ERD-25T J
R161, 261	0B09213A	Fail Safe Type Resistor 150 RDF-25S J
C148, 248	0B01405A	Electrolytic Capacitor 1μ 50V
C149, 249	0B09218A	Electrolytic Capacitor 47μ 16V (LN)
C150, 250	0B09219A	Electrolytic Capacitor 6.8μ 16V (LN)
C151, 251	0B01272A	Electrolytic Capacitor 100μ 25V
	– Bias Osc. –	
Q301, 302	0B06100A	Transistor 2SC945 (A)
303		
T301	0B06613A	Osc. Coil
R301, 302	0B05668A	Carbon Resistor 82K ERD-25T J
R303, 304	0B09212A	Fail Safe Type Resistor 2.2 RDF-25S J
R305	0B01682A	Carbon Resistor 6.8K ERD-25T J
R310	0B09296A	Fail Safe Type Resistor 39 RSF-½B J
R311	0B09295A	Fail Safe Type Resistor 82 RSF-2B J
C301	0B05583A	Mylar Capacitor 0.033μ 50V J
C302, 303	0B09191A	PP Capacitor 4700P 100V G
C304	0B01402A	Electrolytic Capacitor 4.7μ 25V
C305	0B09254A	PP Capacitor 0.068μ 100V J
	– Logic –	
IC402	0B06124B	IC RC4558D
Q401, 403	0B06013A	Transistor 2SA733
411, 416		
418, 419		
423, 424		

Schematic Ref. No.	Part No.	Description
Q425, 429		
431		
Q402, 406	0B06069A	Transistor 2SB564
409, 428		
Q404, 410	0B06100A	Transistor 2SC945 (A)
412, 415		
420, 421		
422, 426		
427, 430		
433		
Q405, 413	0B06066A	Transistor 2SD471
Q407	0B06020A	Transistor 2SC1096
Q408	0B06012A	Transistor 2SA634
Q414	0B06252A	Transistor 2SB564 (K)
Q417	0B06155A	Transistor 2SA733 (P)
Q432	0B06251A	Transistor 2SC945A (Q)
D403-431	0B06181A	Silicon Diode 1SS53 (29 pcs.)
R403, 407	0B01889A	Carbon Resistor 100K ERD-25T J
408, 413		
418, 422		
427, 428		
430, 433		
440, 441		
448, 468		
472, 473		
475, 485		
486, 487		
488, 490		
R404, 446	0B01887A	Carbon Resistor 5.6K ERD-25T J
447		
R405, 424	0B01888A	Carbon Resistor 10K ERD-25T J
435, 449		
450, 451		
459, 461		
462, 467		
493		
R406, 491	0B05575A	Carbon Resistor 560 ERD-25T J
R409, 464	0B05509A	Carbon Resistor 33K ERD-25T J
R410, 425	0B05615A	Carbon Resistor 22K ERD-25T J
426, 460		
466, 474		
477, 478		
479, 483		
R411	0B01682A	Carbon Resistor 6.8K ERD-25T J
R412, 417	0B05627A	Carbon Resistor 330K ERD-25T J
429, 452		
455, 469		
480, 489		
494		
R414, 456	0B05508A	Carbon Resistor 56K ERD-25T J
R415	0B09328A	Metal Film Resistor 9.1K SN14K2E F
R416	0B09340A	Metal Film Resistor 15K SN14K2E F
R419	0B05626A	Carbon Resistor 150K ERD-25T J
R420, 421	0B05671A	Carbon Resistor 2.2M ERD-25T J
R423	0B09214A	Fail Safe Type Resistor 1 RDF-25S J
R431, 432	0B01681A	Carbon Resistor 3.3K ERD-25T J
439, 445		
R434	0B05692A	Carbon Resistor 68K ERD-25T J
R436	0B09314A	Carbon Resistor 5.1K ERD-25T J
R437	0B09384A	Fail Safe Type Resistor 27 ERD-14F J
R438, 443	0B01857A	Carbon Resistor 1K ERD-25T J
465, 471		

Schematic Ref. No.	Part No.	
R442	0B01680A	Carbon Re
R453	0B05621A	Carbon Re
R454, 481	0B09335A	Carbon Re
R457, 458	0B05622A	Carbon Re
R463, 476	0B01846A	Carbon Re
R470	0B01684A	Carbon Re
R484	0B01683A	Carbon Re
C403	0B09286A	Ceramic C
C406, 411	0B09332A	Electrolyti
412		
C407	0B09251A	Electrolyti
C408	0B09283A	Ceramic C
C409	0B09345A	Electrolyti
C414	0B09333A	Electrolyti
C415	0B01272A	Electrolyti
C416	0B01405A	Electrolyti
C417	0B01674A	Electrolyti
C418	0B01676A	Mylar Cap
C419	0B09292A	Ceramic C
C420, 422	0B09290A	Ceramic C
C421	0B09368A	Electrolyt
	– Power Supply –	
IC401	0B06237A	Regulator
D401	0B06183A	Diode Bric
D402	0B05181A	Silicon Di
R309	0B09339A	Fail Safe T
R401	0B01888A	Carbon Re
R402	0B01684A	Carbon Re
C306	0B01870A	Electrolyt
C401, 402	0B01412A	Electrolyt
C404	0B09336A	Electrolyt
C405	0B09373A	Electrolyt
	– Missellaneous –	
	0B07847H	Main P.C.I
	0B01857A	Carbon Re
F401	0B08686A	Fuse
F401	0B08374A	Fuse
F401	0B08275A	Fuse
		(L
F402	0B08698A	Fuse
F402	0B08697A	Fuse
F402	0B08457A	Fuse
		(L
M2	0B08363A	Spark Kill
M2	0B08342A	Spark Kill
M2	0B08240U	Spark Kill
M2, 3	0B08445A	Spark Kill
CN1	0B08654A	4P-T Post
CN2	0B08681A	12P-T Pos
CN3	0B08653A	3P-T Post
CN4	0B08656A	2P-T Post
SW301	0B07239A	Record Sv
	0B07303A	Push Swit
	0B08675A	Pin Jack
	0B08676A	Heat Sink

ion	Schematic Ref. No.	Part No.	Description	Schematic Ref. No.	Part No.	Description	Schematic Ref. No.	Part No.	Description	Schematic Ref. No.	Part No.	Description
0P 50V J	R144, 244	0B09263A	Carbon Resistor 12K ERD-25T J	Q425, 429			R442	0B01680A	Carbon Resistor 820 ERD-25T J		0B08680B	Heat Sink A (1 pce.)
10μ 16V	R145, 245	0B05575A	Carbon Resistor 560 ERD-25T J	431			R453	0B05621A	Carbon Resistor 120K ERD-25T J		0C08144C	Record Spring (1 pce.)
	R147, 247	0B01679A	Carbon Resistor 100 ERD-25T J	Q402, 406	0B06069A	Transistor 2SB564	R454, 481	0B09335A	Carbon Resistor 680K ERD-25T J		0B08569C	Record Wire Holder (1 pce.)
	R148, 149	0B01856A	Carbon Resistor 8.2K ERD-25T J	409, 428			R457, 458	0B05622A	Carbon Resistor 2.2K ERD-25T J		0B08570A	Record Spring Holder (1 pce.)
	248, 249			Q404, 410	0B06100A	Transistor 2SC945 (A)	R463, 476	0B01846A	Carbon Resistor 4.7K ERD-25T J		0B08573A	Wire Holder (1 pce.)
0P 100V G	R150, 151	0B09331A	Fail Safe Type Resistor 8.2 RDF-25S J	412, 415			R470	0B01684A	Carbon Resistor 470K ERD-25T J		0B08349A	Fuse Clip (UK, Australia & 220V Class 2) (4 pcs.)
0P 50V J	250, 251			420, 421			R484	0B01683A	Carbon Resistor 15K ERD-25T J			
33μ 100V G	R152, 252	0B01857A	Carbon Resistor 1K ERD-25T J	422, 426			C403	0B09286A	Ceramic Capacitor 470P 50V K		0M03782A	Fuse Label 1A 250V (U.S.A., Canada, Japan & Others) (1 pc.)
22μ 16V	R153, 253	0B09306A	Fail Safe Type Resistor 68 RDF-25S J	427, 430			C406, 411	0B09332A	Electrolytic Capacitor 2.2μ 25V (LN)			
33μ 50V J	R163, 263	0B05622A	Carbon Resistor 2.2K ERD-25T J	433			412				0M04100B	Fuse Label 500mA 250V (U.S.A., Canada, Japan & Others) (1 pc.)
μ 50V K	R164, 264	0B05641A	Carbon Resistor 47K ERD-25T J	Q405, 413	0B06066A	Transistor 2SD471	C407	0B09251A	Electrolytic Capacitor 33μ 25V			
0.33μ 50V (LN)	R170, 270	0B01679A	Carbon Resistor 100 ERD-25T J	Q407	0B06020A	Transistor 2SC1096	C408	0B09283A	Ceramic Capacitor 220P 50V K			
100μ 10V	C140, 240	0B05652A	Mylar Capacitor 4700P 50V J	Q408	0B06012A	Transistor 2SA634	C409	0B09345A	Electrolytic Capacitor 3.3μ 25V (BP)			
100μ 25V	C141, 145	0B01412A	Electrolytic Capacitor 10μ 16V	Q414	0B06252A	Transistor 2SB564 (K)	C414	0B09333A	Electrolytic Capacitor 4.7μ 25V (LN)		0M04082B	Fuse Label T 125mA 250V (UK, Australia & 220V Class 2) (1 pce.)
	241, 245			Q417	0B06155A	Transistor 2SA733 (P)	C415	0B01272A	Electrolytic Capacitor 100μ 25V			
	C142, 242	0B01862A	Electrolytic Capacitor 22μ 16V	Q432	0B06251A	Transistor 2SC945A (Q)	C416	0B01405A	Electrolytic Capacitor 1μ 50V			
	C146, 147	0B01272A	Electrolytic Capacitor 100μ 25V	D403-431	0B06181A	Silicon Diode 1SS53 (29 pcs.)	C417	0B01674A	Electrolytic Capacitor 10μ 25V		0M04096B	Fuse Label T 500mA 250V (UK, Australia & 220V Class 2) (1 pce.)
945 (L)	246, 247			R403, 407	0B01889A	Carbon Resistor 100K ERD-25T J	C418	0B01676A	Mylar Capacitor 0.056μ 50V			
5mH	C152, 252	0B05653A	Mylar Capacitor 1500P 50V J	408, 413			C419	0B09292A	Ceramic Capacitor 0.1μ 50V Z		0E00612A	Screw M3x6 Philips Pan Head (2A) (2 pcs.)
				418, 422			C420, 422	0B09290A	Ceramic Capacitor 0.01μ 50V Z			
		— Meter Amp. —		427, 428			C421	0B09368A	Electrolytic Capacitor 22μ 25V (BP)		0E00788A	BT Screw M2x8 Philips Pan Head (1 pce.)
				430, 433								
	Q109, 110	0B06100A	Transistor 2SC945 (A)	440, 441				— Power Supply —			0E00831A	BT Screw M3x10 Philips Pan Head (1 pce.)
ERD-25T J	209, 210			448, 468								
	ZD101,201	0B06191A	Zener Diode 2.7EB	472, 473			IC401	0B06237A	Regulator +24V μA7824		0E00857A	BT Screw M3x6 Philips Binding Head (2 pcs.)
	D104, 105	0B06181A	Silicon Diode 1SS53	475, 485			D401	0B06183A	Diode Bridge RB151			
	204, 205			486, 487			D402	0B06181A	Silicon Diode 1SS53			
ERD-25T J	VR105,205	0B07237A	Semi-fixed Volume 50K	488, 490			R309	0B09339A	Fail Safe Type Resistor 3.3 RSF-25S J		0E00507A	Nut Hex. M3 (2 pcs.)
ERD-25T J	R154, 159	0B01889A	Carbon Resistor 100K ERD-25T J	492			R401	0B01888A	Carbon Resistor 10K ERD-25T J		0E00117A	Washer 2mm (1 pc.)
K ERD-25T J	254, 259			R404, 446	0B01887A	Carbon Resistor 5.6K ERD-25T J	R402	0B01684A	Carbon Resistor 470K ERD-25T J		0E00172A	Washer 3mm Toothed Lock (1 pce.)
< ERD-25T J	R155, 255	0B09318A	Metal Film Resistor 560K SN14K2E F	447			C306	0B01870A	Electrolytic Capacitor 1000μ 25V			
ERD-25T J	R156, 256	0B09338A	Metal Film Resistor 390K SN14K2E F	R405, 424	0B01888A	Carbon Resistor 10K ERD-25T J	C401, 402	0B01412A	Electrolytic Capacitor 10μ 16V			
< ERD-25T J	R157, 158	0B01888A	Carbon Resistor 10K ERD-25T J	435, 449			C404	0B09336A	Electrolytic Capacitor 2200μ 50V			
< ERD-25T J	257, 258			450, 451			C405	0B09373A	Electrolytic Capacitor 3300μ 25V			
	R160, 260	0B05691A	Carbon Resistor 390 ERD-25T J	459, 461								
ERD-25T J	R161, 261	0B09213A	Fail Safe Type Resistor 150 RDF-25S J	462, 467				— Missellaneous —				
0P 50V J	C148, 248	0B01405A	Electrolytic Capacitor 1μ 50V	493								
0P 50V J	C149, 249	0B09218A	Electrolytic Capacitor 47μ 16V (LN)	R406, 491	0B05575A	Carbon Resistor 560 ERD-25T J		0B07847H	Main P.C.B.			
0P 50V J	C150, 250	0B09219A	Electrolytic Capacitor 6.8μ 16V (LN)	R409, 464	0B05509A	Carbon Resistor 33K ERD-25T J		0B01857A	Carbon Resistor 1K ERD-25T J (2 pcs.)			
100μ 16V	C151, 251	0B01272A	Electrolytic Capacitor 100μ 25V	R410, 425	0B05615A	Carbon Resistor 22K ERD-25T J						
22μ 16V				426, 460			F401	0B08686A	Fuse 1A 250V (Japan)			
50V J		— Bias Osc. —		466, 474			F401	0B08374A	Fuse 1A 250V (U.S.A., Canada & Others)			
				477, 478								
P 50V J	Q301, 302	0B06100A	Transistor 2SC945 (A)	479, 483			F401	0B08275A	Fuse T 125mA 250V (UK, Australia & 220V Class 2)			
P 100V J	303			R411	0B01682A	Carbon Resistor 6.8K ERD-25T J						
P 50V K	T301	0B06613A	Osc. Coil	R412, 417	0B05627A	Carbon Resistor 330K ERD-25T J	F402	0B08698A	Fuse 500mA 250V (U.S.A., Canada & Others)			
4.7μ 25V	R301, 302	0B05668A	Carbon Resistor 82K ERD-25T J	429, 452								
	R303, 304	0B09212A	Fail Safe Type Resistor 2.2 RDF-25S J	455, 469			F402	0B08697A	Fuse 500mA 250V (Japan)			
	R305	0B01682A	Carbon Resistor 6.8K ERD-25T J	480, 489								
	R310	0B09296A	Fail Safe Type Resistor 39 RSF-½B J	494			F402	0B08457A	Fuse T 500mA 250V (UK, Australia & 220V Class 2)			
945 (L)	R311	0B09295A	Fail Safe Type Resistor 82 RSF-2B J	R414, 456	0B05508A	Carbon Resistor 56K ERD-25T J						
	C301	0B05583A	Mylar Capacitor 0.033μ 50V J	R415	0B09328A	Metal Film Resistor 9.1K SN14K2E F	M2	0B08363A	Spark Killer (Japan)			
	C302, 303	0B09191A	PP Capacitor 4700P 100V G	R416	0B09340A	Metal Film Resistor 15K SN14K2E F	M2	0B08342A	Spark Killer (U.S.A. & Canada)			
733	C304	0B01402A	Electrolytic Capacitor 4.7μ 25V	R419	0B05626A	Carbon Resistor 150K ERD-25T J	M2	0B08240U	Spark Killer (UK, Australia & Others)			
	C305	0B09254A	PP Capacitor 0.068μ 100V J	R420, 421	0B05671A	Carbon Resistor 2.2M ERD-25T J	M2, 3	0B08445A	Spark Killer (220V Class 2)			
53				R423	0B09214A	Fail Safe Type Resistor 1 RDF-25S J	CN1	0B08654A	4P-T Post			
		— Logic —		R431, 432	0B01681A	Carbon Resistor 3.3K ERD-25T J	CN2	0B08681A	12P-T Post			
: ERD-25T J				439, 445			CN3	0B08653A	3P-T Post			
	IC402	0B06124B	IC RC4558D	R434	0B05692A	Carbon Resistor 68K ERD-25T J	CN4	0B08656A	2P-T Post			
ERD-25T J	Q401, 403	0B06013A	Transistor 2SA733	R436	0B09314A	Carbon Resistor 5.1K ERD-25T J	SW301	0B07239A	Record Switch			
< ERD-25T J	411, 416			R437	0B09384A	Fail Safe Type Resistor 27 ERD-14F J		0B07303A	Push Switch (1 pce.)			
	418, 419			R438, 443	0B01857A	Carbon Resistor 1K ERD-25T J		0B08675A	Pin Jack (1 pce.)			
ERD-25T J	423, 424			465, 471				0B08676A	Heat Sink (1 pce.)			

Schematic Ref. No.	Part No.	Description
	BA04130A	**Main P.C.B. Ass'y (U.S.A. & Canada)**
	BA04112A	**Main P.C.B. Ass'y (Japan)**
	BA04131A	**Main P.C.B. Ass'y (220V Class 2)**
	BA04132A	**Main P.C.B. Ass'y (UK & Australia)**
	BA04133A	**Main P.C.B. Ass'y (Others)**
		Serial Nos.: A304.501001 – A304.518704
	– PB Eq. Amp. –	
Q101, 102 201, 202	0B06119A	Transistor 2SC1844
ZD301	0B06239A	Zener Diode RD20EB
L101,201	0B03919B	Inductor 36mH
VR101,201	0B07237A	Semi-fixed Volume 50K
R101, 103 201, 203	0B01889A	Carbon Resistor 100K ERD-25T J
R102, 202	0B01706A	Carbon Resistor 47 ERD-25T J
R104, 106 204, 206	0B05509A	Carbon Resistor 33K ERD-25T J
R105, 205	0B09330A	Carbon Resistor 100K ERD-25TS J (Noiseless)
R107, 109 207, 209 308	0B05622A	Carbon Resistor 2.2K ERD-25T J
R108, 208	0B05614A	Carbon Resistor 1.8K ERD-25T J
R110, 210	0B05621A	Carbon Resistor 120K ERD-25T J
R111, 211	0B05577A	Carbon Resistor 330 ERD-25T J
R112, 212	0B05794A	Carbon Resistor 680 ERD-25T J
R113, 213	0B05641A	Carbon Resistor 47K ERD-25T J
R166, 266	0B05936A	Carbon Resistor 10 ERD-25T J
C101, 201	0B09137A	Electrolytic Capacitor 22μ 16V (LN)
C102, 202	0B09376A	Electrolytic Capacitor 22μ 25V (LN)
C103, 203	0B09283A	Ceramic Capacitor 220P 50V K
C105, 205	0B05885A	Electrolytic Capacitor 100μ 10V
C106, 206	0B09045A	Mylar Capacitor 0.027μ 50V J
C107, 207	0B01412A	Electrolytic Capacitor 10μ 16V
C108, 208	0B01272A	Electrolytic Capacitor 100μ 25V
C109, 209	0B05653A	Mylar Capacitor 1500P 50V J
	– Dolby NR –	
IC101, 201	0B06175A	IC μA7300PC
L102, 202	0B03919B	Inductor 36mH
L103, 203	0B03563A	19K Coil 23mH
R114, 214	0B01846A	Carbon Resistor 4.7K ERD-25T J
R115, 215	0B01888A	Carbon Resistor 10K ERD-25T J
R116, 216	0B05629A	Carbon Resistor 2.7K ERD-25T J
R117, 217	0B01887A	Carbon Resistor 5.6K ERD-25T J
R118, 119 218, 219	0B05509A	Carbon Resistor 33K ERD-25T J
R120, 124 220, 224	0B05620A	Carbon Resistor 270K ERD-25T J
R121, 221	0B09317A	Metal Film Resistor 3.3K SN14K2E F
R122, 222	0B05641A	Carbon Resistor 47K ERD-25T J
R123, 223	0B09271A	Carbon Resistor 6.2K ERD-25T J
R162, 262	0B01857A	Carbon Resistor 1K ERD-25T J
R165, 265	0B09213A	Fail Safe Type Resistor 150 RDF-25S J
R167, 267	0B05776A	Carbon Resistor 1M ERD-25T J
R169, 269	0B05627A	Carbon Resistor 330K ERD-25T J
C110, 210	0B09223A	Electrolytic Capacitor 1μ 50V (LN)
C111, 211	0B01403A	Electrolytic Capacitor 47μ 16V
C112, 212	0B09242A	Mica Capacitor 47P 50V J
C113, 213	0B09262A	PP Capacitor 3000P 50V J
C114, 214	0B01913A	Mylar Capacitor 1800P 50V J
C115, 116 117, 123 215, 216 217, 223	0B01412A	Electrolytic Capacitor 10μ 16V
C118, 218	0B09191A	PP Capacitor 4700P 100V G
C119, 219	0B01804A	Mylar Capacitor 3900P 50V J
C120, 220	0B09240A	PP Capacitor 0.033μ 100V G
C121, 221	0B01862A	Electrolytic Capacitor 22μ 16V
C122, 222	0B05583A	Mylar Capacitor 0.033μ 50V J
C124, 224	0B01603A	Mylar Capacitor 0.1μ 50V K
C125, 225	0B09327A	Electrolytic Capacitor 0.33μ 50V (LN)
C136, 236	0B05885A	Electrolytic Capacitor 100μ10V
C137, 237	0B01272A	Electrolytic Capacitor 100μ 25V
	– Rec. Amp. –	
Q103, 203	0B01872A	Transistor 2SC945 (L)
L104, 105 204, 205	0B00068A	Trap Coil 10.5mH
VR102,103 104,202 203,204	0B07237A	Semi-fixed Volume 50K
R127, 129 131, 137 227, 229 231, 237	0B01683A	Carbon Resistor 15K ERD-25T J
R125, 225	0B09263A	Carbon Resistor 12K ERD-25T J
R126, 226	0B05691A	Carbon Resistor 390 ERD-25T J
R132, 232	0B05621A	Carbon Resistor 120K ERD-25T J
R133, 233	0B01856A	Carbon Resistor 8.2K ERD-25T J
R134, 234	0B01857A	Carbon Resistor 1K ERD-25T J
R135, 235	0B05698A	Carbon Resistor 1.5K ERD-25T J
R136, 168 236, 268	0B05622A	Carbon Resistor 2.2K ERD-25T J
R138, 238	0B01888A	Carbon Resistor 10K ERD-25T J
C126, 226	0B05530A	Mylar Capacitor 6800P 50V J
C127, 227	0B05814A	Mylar Capacitor 8200P 50V J
C128, 228	0B05550A	Mylar Capacitor 1000P 50V J
C129, 229	0B01400A	Electrolytic Capacitor 100μ 16V
C133, 233	0B01862A	Electrolytic Capacitor 22μ 16V
C134, 135 234, 235	0B01780A	Mylar Capacitor 0.1μ 50V J
C138, 238	0B09246A	Mica Capacitor 150P 50V J
C139, 239	0B09323A	PP Capacitor 560P 100V J
C153, 253	0B09282A	Ceramic Capacitor 100P 50V K
C154, 254	0B01389A	Electrolytic Capacitor 4.7μ 25V
	– Line Amp. –	
Q104, 105 107, 204 205, 207	0B01872A	Transistor 2SC945 (L)
Q106, 108 206, 208	0B06013A	Transistor 2SA733
D101, 102 201, 202	0B06181A	Silicon Diode 1SS53
R139, 146 239, 246	0B01681A	Carbon Resistor 3.3K ERD-25T J
R140, 240	0B05641A	Carbon Resistor 47K ERD-25T J
R141, 143 241, 243	0B05626A	Carbon Resistor 150K ERD-25T J
R142, 242	0B05509A	Carbon Resistor 33K ERD-25T J
R144, 244	0B09263A	Carbon Resistor 12K ERD-25T J
R145, 245	0B05575A	Carbon Resistor 560 ERD-25T J
R147, 247	0B01679A	Carbon Resistor 100 ERD-25T J
R148, 149 248, 249	0B01856A	Carbon Resistor 8.2K ERD-25T J
R150, 151 250, 251	0B09331A	Fail Safe Type Resistor 8.2 RDF-25S J
R152, 252	0B01857A	Carbon Resistor 1K ERD-25T J
R153, 253	0B09306A	Fail Safe Type Resistor 68 RDF-25S J
R163, 263	0B05622A	Carbon Resistor 2.2K ERD-25T J
R164, 264	0B05641A	Carbon Resistor 47K ERD-25T J
R170, 270	0B01679A	Carbon Resistor 100 ERD-25T J
C140, 240	0B05652A	Mylar Capacitor 4700P 50V J
C141, 145 241, 245	0B01412A	Electrolytic Capacitor 10μ 16V
C142, 242	0B01862A	Electrolytic Capacitor 22μ 16V
C146, 147 246, 247	0B01272A	Electrolytic Capacitor 100μ 25V
C152, 252	0B05653A	Mylar Capacitor 1500P 50V J
	– Meter Amp. –	
Q109, 110 209, 210	0B06100A	Transistor 2SC945 (A)
ZD101,201	0B06191A	Zener Diode 2.7EB
D104, 150 204, 205	0B06181A	Silicon Diode 1SS53
VR105, 205	0B07237A	Semi-fixed Volume 50K
R154, 159 254, 259	0B01889A	Carbon Resistor 100K ERD-25T J
R155, 255	0B09318A	Metal Film Resistor 560K SN14K2E F
R156, 256	0B09338A	Metal Film Resistor 390K SN14K2E F
R157, 158 257, 258	0B01888A	Carbon Resistor 10K ERD-25T J
R160, 260	0B05691A	Carbon Resistor 390 ERD-25T J
R161, 261	0B09213A	Fail Safe Type Resistor 150 RDF-25S J
C148, 248	0B01405A	Electrolytic Capacitor 1μ 50V
C149, 249	0B09218A	Electrolytic Capacitor 47μ 16V (LN)
C150, 250	0B09219A	Electrolytic Capacitor 6.8μ 16V (LN)
C151, 251	0B01272A	Electrolytic Capacitor 100μ 25V
	– Bias Osc. –	
Q301, 302 303	0B06100A	Transistor 2SC945 (A)
T301	0B06613A	Osc. Coil
R301, 302	0B05668A	Carbon Resistor 82K ERD-25T J
R303, 304	0B09212A	Fail Safe Type Resistor 2.2 RDF-25S J
R305	0B01682A	Carbon Resistor 6.8K ERD-25T J
R310	0B09296A	Fail Safe Type Resistor 39 RSF-1/2B J
R311	0B09295A	Fail Safe Type Resistor 82 RSF-2B J
C301	0B05583A	Mylar Capacitor 0.033μ 50V J
C302, 303	0B09191A	PP Capacitor 4700P 100V G
C304	0B01402A	Electrolytic Capacitor 4.7μ 25V
C305	0B09254A	PP Capacitor 0.068μ 100V J
	– Logic –	
IC402	0B06124B	IC RC4558D
Q401, 403 411, 416	0B06013A	Transistor 2SA733
417, 418		
419, 423		
424, 425		
429, 431		
Q402, 406 409, 428	0B06069A	Transistor 2SB564
Q404, 410 412, 415	0B06100A	Transistor 2SC945 (A)
420, 421		
422, 426		
427, 430		
433		
Q405, 413	0B06066A	Transistor 2SD471
Q407	0B06020A	Transistor 2SC1096
Q408, 414	0B06012A	Transistor 2SA634
Q432	0B06251A	Transistor 2SC945A (Q)
D403-429	0B06181A	Silicon Diode 1SS53 (27 pcs.)
R403, 407 408, 413	0B01889A	Carbon Resistor 100K ERD-25T J
418, 422 427, 428		
430, 433 440, 441		
448, 468 472, 473		
475, 485 486, 487 488, 490 492		
R404, 446 447	0B01887A	Carbon Resistor 5.6K ERD-25T J
R405, 424 435, 449	0B01888A	Carbon Resistor 10K ERD-25T J
450, 451 459, 461		
462, 467 493		
R406, 491	0B05575A	Carbon Resistor 560 ERD-25T J
R409, 464	0B05509A	Carbon Resistor 33K ERD-25T J
R410, 425 426, 442 460, 466	0B05615A	Carbon Resistor 22K ERD-25T J
474, 477 478, 479 483		
R411, 439	0B01682A	Carbon Resistor 6.8K ERD-25T J
R412, 417 429, 452 455, 469 480, 489 494	0B05627A	Carbon Resistor 330K ERD-25T J
R414, 456	0B05508A	Carbon Resistor 56K ERD-25T J
R415	0B09328A	Metal Film Resistor 9.1K SN14K2E F
R416	0B09340A	Metal Film Resistor 15K SN14K2E F
R419	0B05626A	Carbon Resistor 150K ERD-25T J
R420, 421 R423	0B05671A 0B09214A	Carbon Resistor 2.2M ERD-25T J Fail Safe Type Resistor 1 RDF-25S J
R431, 432 445	0B01681A	Carbon Resistor 3.3K ERD-25T J
R434	0B05692A	Carbon Resistor 68K ERD-25T J
R436	0B09314A	Carbon Resistor 5.1K ERD-25T J
R437	0B09049A	Fail Safe Type Resistor 22 ERD-14F J
R438	0B05614A	Carbon Resi
R443, 465 471	0B01857A	Carbon Resi
R453	0B05621A	Carbon Resi
R454, 481	0B09335A	Carbon Resi
R457, 458	0B05622A	Carbon Resi
R463, 476	0B01846A	Carbon Resi
R470	0B01684A	Carbon Resi
R484	0B01683A	Carbon Resi
C403	0B09286A	Ceramic Cap
C406, 411 412	0B09332A	Electrolytic
C407	0B09251A	Electrolytic
C408	0B09283A	Ceramic Cap
C409	0B09345A	Electrolytic
C414	0B09333A	Electrolytic
C415	0B01272A	Electrolytic
C416	0B01405A	Electrolytic
C417	0B01674A	Electrolytic
C418	0B01676A	Mylar Capac
C419	0B09292A	Ceramic Cap
C420	0B09290A	Ceramic Cap
C421	0B09368A	Electrolytic
	– Power Supply –	
IC401	0B06237A	Regulator +
D401	0B06183A	Diode Bridg
D402	0B06181A	Silicon Dioc
R309	0B09339A	Fail Safe Ty
R401	0B01888A	Carbon Res
R402	0B01684A	Carbon Res
C306	0B01870A	Electrolytic
C401, 402	0B01412A	Electrolytic
C404	0B09336A	Electrolytic
C405	0B09373A	Electrolytic
	– Miscellaneous –	
	0B07847D	Main P.C.B.
	0B01857A	Carbon Res
F401	0B08686A	Fuse
F401	0B08374A	Fuse (U.S.A., Ca
F401	0B08275A	Fuse (UK, Austr
F402	0B08698A	Fuse (U.S.A., Ca
F402	0B08697A	Fuse (Japan)
F402	0B08457A	Fuse (UK, Austr
M2	0B08363A	Spark Killer
M2	0B08342A	Spark Killer
M2	0B08240U	Spark Killer
M2, 3	0B08445A	Spark Killer
CN1	0B08654A	4P-T Post
CN2	0B08681A	12P-T Post
CN3	0B08653A	3P-T Post
CN4	0B08656A	2P-T Post
SW301	0B07239A	Record Swi

ption	Schematic Ref. No.	Part No.	Description	Schematic Ref. No.	Part No.	Description	Schematic Ref. No.	Part No.	Description	Schematic Ref. No.	Part No.	Description
1800P 50V J	R142, 242	0B05509A	Carbon Resistor 33K ERD-25T J	417, 418			R438	0B05614A	Carbon Resistor 1.8K ERD-25T J		0B07303A	Push Switch (1 pce.)
tor 10μ 16V	R144, 244	0B09263A	Carbon Resistor 12K ERD-25T J	419, 423			R443, 465	0B01857A	Carbon Resistor 1K ERD-25T J		0B08675A	Pin Jack (1 pce.)
	R145, 245	0B05575A	Carbon Resistor 560 ERD-25T J	424, 425			471				0B08676A	Heat Sink (1 pce.)
	R147, 247	0B01679A	Carbon Resistor 100 ERD-25T J	429, 431			R453	0B05621A	Carbon Resistor 120K ERD-25T J		0B08680B	Heat Sink A (1 pce.)
	R148, 149	0B01856A	Carbon Resistor 8.2K ERD-25T J	Q402, 406	0B06069A	Transistor 2SB564	R454, 481	0B09335A	Carbon Resistor 680K ERD-25T J		0C08144C	Record Spring (1 pce.)
4700P 100V G	248, 249			409, 428			R457, 458	0B05622A	Carbon Resistor 2.2K ERD-25T J		0B08569C	Record Wire Holder (1 pce.)
3900P 50V J	R150, 151	0B09331A	Fail Safe Type Resistor 8.2 RDF-25S J	Q404, 410	0B06100A	Transistor 2SC945 (A)	R463, 476	0B01846A	Carbon Resistor 4.7K ERD-25T J		0B08570A	Record Spring Holder (1 pce.)
0.033μ 100V G	250, 251			412, 415			R470	0B01684A	Carbon Resistor 470K ERD-25T J		0B08573A	Wire Holder (1 pce.)
tor 22μ 16V	R152, 252	0B01857A	Carbon Resistor 1K ERD-25T J	420, 421			R484	0B01683A	Carbon Resistor 15K ERD-25T J		0B08349A	Fuse Clip
0.033μ 50V J	R153, 253	0B09306A	Fail Safe Type Resistor 68 RDF-25S J	422, 426			C403	0B09286A	Ceramic Capacitor 470P 50V K			(UK, Australia & 220V Class 2) (4 pcs.)
0.1μ 50V K	R163, 263	0B05622A	Carbon Resistor 2.2K ERD-25T J	427, 430			C406, 411	0B09332A	Electrolytic Capacitor 2.2μ 25V (LN)		0M03782A	Fuse Label 1A 250V
tor 0.33μ 50V (LN)	R164, 264	0B05641A	Carbon Resistor 47K ERD-25T J	433			412					(U.S.A., Canada, Japan & Others) (1 pce.)
tor 100μ10V	R170, 270	0B01679A	Carbon Resistor 100 ERD-25T J	Q405, 413	0B06066A	Transistor 2SD471	C407	0B09251A	Electrolytic Capacitor 33μ 25V		0M04100B	Fuse Label 500mA 250V
tor 100μ 25V	C140, 240	0B05652A	Mylar Capacitor 4700P 50V J	Q407	0B06020A	Transistor 2SC1096	C408	0B09283A	Ceramic Capacitor 220P 50V K			(U.S.A., Canada, Japan & Others) (1 pce.)
	C141, 145	0B01412A	Electrolytic Capacitor 10μ 16V	Q408, 414	0B06012A	Transistor 2SA634	C409	0B09345A	Electrolytic Capacitor 3.3μ 25V (BP)		0M04082B	Fuse Label T 125mA 250V
	241, 245			Q432	0B06251A	Transistor 2SC945A (Q)	C414	0B09333A	Electrolytic Capacitor 4.7μ 25V (LN)			(UK, Australia & 220V Class 2) (1 pce.)
	C142, 242	0B01862A	Electrolytic Capacitor 22μ 16V	D403-429	0B06181A	Silicon Diode 1SS53 (27 pcs.)	C415	0B01272A	Electrolytic Capacitor 100μ 25V		0M04096B	Fuse Label T 500mA 250V
2SC945 (L)	C146, 147	0B01272A	Electrolytic Capacitor 100μ 25V	R403, 407	0B01889A	Carbon Resistor 100K ERD-25T J	C416	0B01405A	Electrolytic Capacitor 1μ 50V			(UK, Australia & 220V Class 2) (1 pce.)
10.5mH	246, 247			408, 413			C417	0B01674A	Electrolytic Capacitor 10μ 25V		0E00612A	Screw M3x6 Philips Pan Head (2A)
	C152, 252	0B05653A	Mylar Capacitor 1500P 50V J	418, 422			C418	0B01676A	Mylar Capacitor 0.056μ 50V			(2 pcs.)
50K				427, 428			C419	0B09292A	Ceramic Capacitor 0.1μ 50V Z		0E00788A	BT Screw M2x8 Philips Pan Head
		— Meter Amp. —		430, 433			C420	0B09290A	Ceramic Capacitor 0.01μ 50V Z			(1 pce.)
				440, 441			C421	0B09368A	Electrolytic Capacitor 22μ 25V (BP)		0E00831A	BT Screw M3x10 Philips Pan Head
15K ERD-25T J	Q109, 110	0B06100A	Transistor 2SC945 (A)	448, 468								(1 pce.)
	209, 210			472, 473				— Power Supply —			0E00857A	BT Screw M3x6 Philips Binding Head
	ZD101,201	0B06191A	Zener Diode 2.7EB	475, 485								(2 pcs.)
	D104, 150	0B06181A	Silicon Diode 1SS53	486, 487			IC401	0B06237A	Regulator +24V μA7824		0E00507A	Nut Hex. M3 (2 pcs.)
12K ERD-25T J	204, 205			488, 490			D401	0B06183A	Diode Bridge RB151		0E00117A	Washer 2mm (1 pce.)
390 ERD-25T J	VR105, 205	0B07237A	Semi-fixed Volume 50K	492			D402	0B06181A	Silicon Diode 1SS53		0E00172A	Washer 3mm Toothed Lock (1 pce.)
120K ERD-25T J	R154, 159	0B01889A	Carbon Resistor 100K ERD-25T J	R404, 446	0B01887A	Carbon Resistor 5.6K ERD-25T J	R309	0B09339A	Fail Safe Type Resistor 3.3 RSF-25S J			
8.2K ERD-25T J	254, 259			447			R401	0B01888A	Carbon Resistor 10K ERD-25T J			
1K ERD-25T J	R155, 255	0B09318A	Metal Film Resistor 560K SN14K2E F	R405, 424	0B01888A	Carbon Resistor 10K ERD-25T J	R402	0B01684A	Carbon Resistor 470K ERD-25T J			
1.5K ERD-25T J	R156, 256	0B09338A	Metal Film Resistor 390K SN14K2E F	435, 449			C306	0B01870A	Electrolytic Capacitor 1000μ 25V			
2.2K ERD-25T J	R157, 158	0B01888A	Carbon Resistor 10K ERD-25T J	450, 451			C401, 402	0B01412A	Electrolytic Capacitor 10μ 16V			
	257, 258			459, 461			C404	0B09336A	Electrolytic Capacitor 2200μ 50V			
10K ERD-25T J	R160, 260	0B05691A	Carbon Resistor 390 ERD-25T J	462, 467			C405	0B09373A	Electrolytic Capacitor 3300μ 25V			
6800P 50V J	R161, 261	0B09213A	Fail Safe Type Resistor 150 RDF-25S J	493								
8200P 50V J	C148, 248	0B01405A	Electrolytic Capacitor 1μ 50V	R406, 491	0B05575A	Carbon Resistor 560 ERD-25T J		— Miscellaneous —				
1000P 50V J	C149, 249	0B09218A	Electrolytic Capacitor 47μ 16V (LN)	R409, 464	0B05509A	Carbon Resistor 33K ERD-25T J						
tor 100μ 16V	C150, 250	0B09219A	Electrolytic Capacitor 6.8μ 16V (LN)	R410, 425	0B05615A	Carbon Resistor 22K ERD-25T J		0B07847D	Main P.C.B.			
tor 22μ 16V	C151, 251	0B01272A	Electrolytic Capacitor 100μ 25V	426, 442				0B01857A	Carbon Resistor 1K ERD-25T J (2 pcs.)			
0.1μ 50V J				460, 466								
		— Bias Osc. —		474, 477			F401	0B08686A	Fuse 1A 250V (Japan)			
150P 50V J				478, 479			F401	0B08374A	Fuse 1A 250V (U.S.A., Canada & Others)			
560P 100V J	Q301, 302	0B06100A	Transistor 2SC945 (A)	483								
100P 50V K	303			R411, 439	0B01682A	Carbon Resistor 6.8K ERD-25T J	F401	0B08275A	Fuse T 125mA 250V (UK, Australia & 220V Class 2)			
tor 4.7μ 25V	T301	0B06613A	Osc. Coil	R412, 417	0B05627A	Carbon Resistor 330K ERD-25T J						
	R301, 302	0B05668A	Carbon Resistor 82K ERD-25T J	429, 452			F402	0B08698A	Fuse 500mA 250V (U.S.A., Canada & Others)			
	R303, 304	0B09212A	Fail Safe Type Resistor 2.2 RDF-25S J	455, 469								
	R305	0B01682A	Carbon Resistor 6.8K ERD-25T J	480, 489			F402	0B08697A	Fuse 500mA 250V (Japan)			
2SC945 (L)	R310	0B09296A	Fail Safe Type Resistor 39 RSF-1/2B J	494								
	R311	0B09295A	Fail Safe Type Resistor 82 RSF-2B J	R414, 456	0B05508A	Carbon Resistor 56K ERD-25T J	F402	0B08457A	Fuse T 500mA 250V (UK, Australia & 220V Class 2)			
	C301	0B05583A	Mylar Capacitor 0.033μ 50V J	R415	0B09328A	Metal Film Resistor 9.1K SN14K2E F						
2SA733	C302, 303	0B09191A	PP Capacitor 4700P 100V G	R416	0B09340A	Metal Film Resistor 15K SN14K2E F	M2	0B08363A	Spark Killer (Japan)			
	C304	0B01402A	Electrolytic Capacitor 4.7μ 25V	R419	0B05626A	Carbon Resistor 150K ERD-25T J	M2	0B08342A	Spark Killer (U.S.A. & Canada)			
1SS53	C305	0B09254A	PP Capacitor 0.068μ 100V J	R420, 421	0B05671A	Carbon Resistor 2.2M ERD-25T J	M2	0B08240U	Spark Killer (UK, Australia & Others)			
				R423	0B09214A	Fail Safe Type Resistor 1 RDF-25S J						
3.3K ERD-25T J		— Logic —		R431, 432	0B01681A	Carbon Resistor 3.3K ERD-25T J	M2, 3	0B08445A	Spark Killer (220V Class 2)			
				445			CN1	0B08654A	4P-T Post			
47K ERD-25T J	IC402	0B06124B	IC RC4558D	R434	0B05692A	Carbon Resistor 68K ERD-25T J	CN2	0B08681A	12P-T Post			
150K ERD-25T J	Q401, 403	0B06013A	Transistor 2SA733	R436	0B09314A	Carbon Resistor 5.1K ERD-25T J	CN3	0B08653A	3P-T Post			
	411, 416			R437	0B09049A	Fail Safe Type Resistor 22 ERD-14F J	CN4	0B08656A	2P-T Post			
							SW301	0B07239A	Record Switch			



Note: Diode is 1SS53 unless otherwise specified.

Fig. 8.8.2 Serial Nos.: A304.501001 – A304.518704

9. MECHANISM ASS'Y AND PARTS LIST

9.1. Synthesis



Fig. 9.1

Schematic Ref. No.	Part No.	Description	Q'ty	Schematic Ref. No.	Part No.	Description	Q'ty
		Synthesis			JA03631A	Synthesis Mechanism Ass'y (Australia)	1
01	0H03768A	Top Cover Ass'y	1		JA03632A	Synthesis Mechanism Ass'y (UK)	1
02	0H03769B	Bottom Cover Ass'y	1		JA03633A	Synthesis Mechanism Ass'y (Others)	1
03	0J03564A	Leg T-H	4				
04	0H03794B	Volume Knob	2	09	0H03781A	Cushion	6
05	0J04066C	Power Switch Joint Bar	1	10	0M04101A	Caution Label	2
06	HA03871A	Front Panel Ass'y	1	L01	0E00858A	BT Screw M4x6 Philips Binding Head (Black Chromate)	4
07	HA03872A	Cassette Case Cover Ass'y	1				
08	JA03629A	Synthesis Mechanism Ass'y (U.S.A. & Canada)	1	L02	0E00736A	Washer 4mm (Black Chromate)	4
				L03	0E00857A	BT Screw M3x6 Philips Binding Head	11
	JA03628A	Synthesis Mechanism Ass'y (Japan)	1				
				L04	0E00865A	BT Screw M3x10 Philips Binding Head	4
	JA03630A	Synthesis Mechanism Ass'y (220V Class 2)	1				

9.2. Front Panel Ass'y (A01)



Fig. 9.2

9.3. Synthesis Mechanism Ass'y (A02)



Fig. 9.3

9.4. Meter Escutcheon Ass'y (B01)



Fig. 9.4

Schematic Ref. No.	Part No.	Description	Q'ty
A01	**HA03871A**	**Front Panel Ass'y**	**1**
01	0H03795B	Front Panel	1
02	HA03873A	Push Button Ass'y C	7
03	HA03874A	Push Button Ass'y D	1
04	HA03875A	Eject Button Ass'y	1
05	0H03744A	Green Lens	2
06	0H03745A	Orange Lens	1
07	0J04094A	Control Button Pad	1
—	0J04081A	Adhesive Tape 55x6	5
—	0J04082A	Adhesive Tape 30x6	2
A02	**JA03629A**	**Synthesis Mechanism Ass'y (U.S.A. & Canada)**	**1**
	JA03628A	**Synthesis Mechanism Ass'y (Japan)**	**1**
	JA03630A	**Synthesis Mechanism Ass'y (220V Class 2)**	**1**
	JA03631A	**Synthesis Mechanism Ass'y (Australia)**	**1**
	JA03632A	**Synthesis Mechanism Ass'y (UK)**	**1**
	JA03633A	**Synthesis Mechanism Ass'y (Others)**	**1**
01	HA03851A	Meter Escutcheon Ass'y	1
02	JA03627A	Control Switch Holder Ass'y	1
03	BA04127A	Switch P.C.B. Ass'y	1
04	JA03616A	Headphone Jack Ass'y	1
05	CA08112A	Mechanism Ass'y 480	1

Schematic Ref. No.	Part No.	Description	Q'ty
06	JA03611A	Chassis Ass'y (U.S.A. & Canada)	1
	JA03610A	Chassis Ass'y (Japan)	1
	JA03612A	Chassis Ass'y (220V Class 2)	1
	JA03613A	Chassis Ass'y (Australia)	1
	JA03614A	Chassis Ass'y (UK)	1
	JA03615A	Chassis Ass'y (Others)	1
07	0B08515A	Insu-Lock	18
L01	0E00857A	BT Screw M3x6 Philips Binding Head	5
L02	0E00502A	Screw M3x5 Philips Pan Head	2
L03	0E00878A	BT Screw M4x20 Philips Binding Head	1
L04	0E00867A	BT Screw M4x15 Philips Binding Head	3
B01	**HA03851A**	**Meter Escutcheon Ass'y**	**1**
01	0H03770B	Meter Escutcheon	1
02	0H03786A	Volume Cover	1
03	BA04110B	Meter Ass'y	1
04	BA04124A	Lamp P.C.B. R Ass'y	1
05	BA04125A	Lamp P.C.B. L Ass'y	1
06	0H03785A	Filter Cover	2
—	0H03771B	Aluminum Seal	1

9.5. Control Switch Holder Ass'y (B02)



Fig. 9.5

9.6. Headphone Jack Ass'y (B03)



Fig. 9.6

Schematic Ref. No.	Part No.	Description	Q'ty	Schematic Ref. No.	Part No.	Description	Q'ty
B02	**JA03627A**	**Control Switch Holder Ass'y**	**1**	**B03**	**JA03616A**	**Headphone Jack Ass'y**	**1**
01	0H03793A	Control Button	6	01	0B08511A	Headphone Jack	1
02	0J04071C	Control Switch Holder	1	02	0J04070A	Headphone Jack Holder	1
03	0J04072B	Lamp Cover	3	L01	–	Jack Nut	(1)
04	0J04073A	Control Button Shaft	1	L02	–	Jack Washer	(1)
05	0J04074D	Control Button Spring	1				
06	BA04113A	Control Switch P.C.B. Ass'y	1				
07	BA04114A	Volume P.C.B. Ass'y	1				
L01	0E00857A	BT Screw M3x6 Philips Binding Head	2				
L02	0E00502A	Screw M3x5 Philips Pan Head	6				
L03	0E00117A	Washer 2mm	2				

9.8. Chassis Ass'y (B05)



Fig. 9.8

9.9. Flywheel Holder Ass'y (C01)



Fig. 9.9

Schematic Ref. No.	Part No.	Description	Q'ty
B05	**JA03611A**	**Chassis Ass'y (U.S.A. & Canada)**	**1**
	JA03610A	**Chassis Ass'y (Japan)**	**1**
	JA03612A	**Chassis Ass'y (220V Class 2)**	**1**
	JA03613A	**Chassis Ass'y (Australia)**	**1**
	JA03614A	**Chassis Ass'y (UK)**	**1**
	JA03615A	**Chassis Ass'y (Others)**	**1**
		Serial No.: A304.518705 –	
01	0J04068B	Front Chassis	1
02	0J04069B	Side Chassis	2
03	0B08720A	Plastic Rivet	3
04	BA04130B	Main P.C.B. Ass'y (U.S.A. & Canada)	1
	BA04112B	Main P.C.B. Ass'y (Japan)	1
	BA04131B	Main P.C.B. Ass'y (220V Class 2)	1
	BA04132B	Main P.C.B. Ass'y (UK & Australia)	1
	BA04133B	Main P.C.B. Ass'y (Others)	1
05	HA03856A	Rear Panel Ass'y (U.S.A. & Canada)	1
	HA03855A	Rear Panel Ass'y (Japan)	1
	HA03857A	Rear Panel Ass'y (220V Class 2)	1
	HA03858A	Rear Panel Ass'y (Australia)	1
	HA03859A	Rear Panel Ass'y (UK)	1
	HA03860A	Rear Panel Ass'y (Others)	1
06	0C08240A	Contact Wire	1
* 07	0M03700A	Earth Mark Label	1
L01	0E00502A	Screw M3x5 Philips Pan Head	2
*L02	0E00857A	BT Screw M3x6 Philips Binding Head	11
L03	0E00860A	BT Screw M3x6 Philips Binding Head (Black Chromate)	1
L04	0E00624A	Screw M3x10 Philips Pan Head (2A)	1
L05	0E00178A	Washer 3mm	1
L06	0E00507A	Nut Hex. M3	2
*L07	0E00037A	Earth Lug B-5	1
		*: Depends on the versions.	
B05	**JA03611A**	**Chassis Ass'y (U.S.A. & Canada)**	**1**
	JA03610A	**Chassis Ass'y (Japan)**	**1**
	JA03612A	**Chassis Ass'y (220V Class 2)**	**1**
	JA03613A	**Chassis Ass'y (Australia)**	**1**
	JA03614A	**Chassis Ass'y (UK)**	**1**
	JA03615A	**Chassis Ass'y (Others)**	**1**
		Serial Nos.: A304.501001 – A304.518704	
01	0J04068B	Front Chassis	1
02	0J04069B	Side Chassis	2
03	0B08539A	Plastic Rivet	3
04	BA04130A	Main P.C.B. Ass'y (U.S.A. & Canada)	1
	BA04112A	Main P.C.B. Ass'y (Japan)	1
	BA04131A	Main P.C.B. Ass'y (220V Class 2)	1
	BA04132A	Main P.C.B. Ass'y (UK & Australia)	1
	BA04133A	Main P.C.B. Ass'y (Others)	1
05	HA03856A	Rear Panel Ass'y (U.S.A. & Canada)	1
	HA03855A	Rear Panel Ass'y (Japan)	1
	HA03857A	Rear Panel Ass'y (220V Class 2)	1
	HA03858A	Rear Panel Ass'y (Australia)	1
	HA03859A	Rear Panel Ass'y (UK)	1
	HA03860A	Rear Panel Ass'y (Others)	1
06	0C08240A	Contact Wire	1
*07	0M03700A	Earth Mark Label	1
L01	0E00502A	Screw M3x5 Philips Pan Head	2
*L02	0E00857A	BT Screw M3x6 Philips Binding Head	11
L03	0E00860A	BT Screw M3x6 Philips Binding Head (Black Chromate)	1
L04	0E00624A	Screw M3x10 Philips Pan Head (2A)	1
L05	0E00178A	Washer 3mm	1
L06	0E00507A	Nut Hex. M3	2
*L07	0E00037A	Earth Lug B-5	1
		*: Depends on the versions.	
C01	**CA08109A**	**Flywheel Holder Ass'y**	**1**
01	0C08013I	Flywheel Holder	1
02	BA04126A	Control P.C.B. Ass'y	1
03	0C08219A	Capstan Motor	1
04	0C08212B	Capstan Motor Pulley	1
05	0M04077A	Motor Seal	1
L01	0E00226A	Screw M2.6x4 Philips Pan Head	3
L02	0E00843A	BT Screw M3x5 Philips Pan Head	1
L03	0C08068C	Thrust Screw	2
L04	0C03857A	Lock Nut	2

9.10. Sub Mechanism Chassis Ass'y (C02)



Fig. 9.10

Schematic Ref. No.	Part No.	Description	Q'ty	Schematic Ref. No.	Part No.	Description	Q'ty
C02	**CA08108A**	**Sub Mechanism Chassis Ass'y**	**1**	L06	0E00843A	BT Screw M2.6x4 Philips Pan Head	1
01	0C08039B	Reel Hub Head	2	L07	0E00037A	Earth Lug B-5	1
02	CA08038B	Reel Hub B Ass'y	2	L08	–	Volume Nut	(1)
03	CA08037A	Reel Hub Take-up Ass'y	1	L09	–	Volume Washer	(1)
04	CA08064A	Reel Hub Supply Ass'y	1				
05	CA08039A	Back Tension Ass'y	1				
06	0C08178A	Back Tension Spring	1				
07	CA08040A	Idler Ass'y	1				
08	0C08127B	Idler Arm Spring	1				
09	CA08042A	Brake Arm Ass'y	2				
10	0C08030C	Brake Drive Arm	1				
11	0C08029A	Brake Arm Spring	1				
12	0C08128A	Brake Drive Arm Spring	1				
13	CA08117B	Reel Motor Ass'y	1				
14	CA08124A	Control Motor Ass'y	1				
15	0C08053B	Volume Coupler	1				
16	0B07240A	Volume Control 10 KΩ (B)	1				
17	0B09091A	Ceramic Capacitor 0.01μ 50V	2				
18	CA08041A	Sub Chassis Ass'y	1				
L01	0E00842A	Stopper Ring 2mm	1				
L02	0E00837A	Stopper Ring 3mm	2				
L03	0E00838A	Stopper Ring 4mm	1				
L04	0E00859A	BT Screw M2.6x6 Philips Binding Head	1				
L05	0E00226A	Screw M2.6x4 Philips Pan Head	5				

Schematic Ref. No.	Part No.	Description	Q'ty
C03	**CA08110A**	**Main Mechanism Chassis Ass'y**	**1**
01	CA08141A	Cassette Case Holder L Ass'y	1
02	CA08022A	Cassette Case Holder R Ass'y	1
03	CA08111A	Cassette Case Ass'y	1
04	0C08019I	Cover Plate	1
05	0M03977A	Cassette Viewer Label	1
06	CA08120A	Head Mount Base Ass'y	1
07	0C08121A	Supply Pressure Roller Spring	2
08	CA08053B	Supply Pressure Roller Ass'y	1
09	0C08122B	Supply Pressure Roller Thrust Spring	1
10	CA08079B	Take-up Pressure Roller Ass'y	1
11	0C08183B	Take-up Pressure Roller Thrust Spring	1
12	0C08182A	Pressure Roller Drive Bar	1
13	CA08121A	Head Base Ass'y C	1
14	0C08086B	Head Base Roller	3
15	0C08050B	Record Sensor	1
16	0C08051E	Cassette Hold Arm	1
17	0C08120A	Cassette Hold Arm Spring	1
18	CA08027A	Head Base Drive Arm Ass'y	1
19	0C08143C	Head Base Drive Arm Spring	1
20	CA08025A	Record Arm Ass'y	1
21	0C08038D	Record Trigger	1
22	0C08112A	Flip-Flop Spring	1
23	CA08026A	Pressure Roller Drive Arm Ass'y	1
24	0C08071D	Counter Reset Arm	1
25	0C08124B	Eject Linkage Wire	1
26	0C08057D	Eject Arm	1
27	0C08078B	Arm Shaft	1
28	CA08119A	Auto Shut-off Ass'y	1
29	CA08020A	Counter Ass'y	1
30	0C08097B	Counter Belt A	1
31	0C08067C	Eject Stopper	1
32	0C08134C	Eject Stopper Spring	1
33	0C08119A	Record Protector	1
34	0C08194C	Damper Lock Arm	1
35	0C08153A	Damper Arm Spring Tube	1
36	CA08030A	Pneumatic Damper Ass'y	1
37	CA08023A	Supply Capstan Flange Ass'y	1
38	CA08024A	Take-up Capstan Flange Ass'y	1
39	0C08186A	Cam Drive Gear	1
40	0C08029H	Control Cam	1
41	0C08152A	Counter-Load Arm Spring Tube	1
42	0C08117A	Counter-Load Arm Spring	1
43	CA08028A	Counter-Load Arm Ass'y	1
44	0C08123B	Record Switch Linkage Wire	1
45	0C08037E	Record Arm B	1
46	0C08116A	Record Arm Spring	2
47	CA08072A	Main Chassis Ass'y	1
48	0C08225A	Shield Plate	1
L01	0E00837A	Stopper Ring 3mm	13
L02	0E00832A	BT Screw M3x14 Philips Pan Head	2
L03	0E00834A	BT Screw M3x30 Philips Pan Head	2
L04	0E00831A	BT Screw M3x10 Philips Pan Head	4
L05	0E00254A	Washer 3.1mm Plastics	2
L06	0E00222A	E-Ring 2mm	2
L07	0E00839A	Stopper Ring 2.5mm	2
L08	0E00876A	BT Screw M2.6x8 Philips Pan Head	11
L09	0C08060B	Height Adjustment Nut	2
L10	0E00142A	Washer 2.6mm	2
L11	0E00879A	BT Screw M2x15 Philips Pan Head	1
L12	0E00838A	Stopper Ring 4mm	3
L13	0E00846A	BT Screw M3x8 Philips Pan Head	3
L14	0E00895A	Earth Lug 3mm	2

9.11. Main Mechanism Chassis Ass'y (C03)



Fig. 9.11

9.12. Rear Panel Ass'y (D01)





Fig. 9.12

Schematic Ref. No.	Part No.	Description	Q'ty
D01	**HA03856A**	**Rear Panel Ass'y (U.S.A. & Canada)**	**1**
	HA03855A	**Rear Panel Ass'y (Japan)**	**1**
	HA03857A	**Rear Panel Ass'y (220V Class 2)**	**1**
	HA03858A	**Rear Panel Ass'y (Australia)**	**1**
	HA03859A	**Rear Panel Ass'y (UK)**	**1**
	HA03860A	**Rear Panel Ass'y (Others)**	**1**
01	0B08533A	Power Cord (U.S.A., Canada & Others)	1
	0B08219B	Power Cord (Japan)	1
	0B08093U	Power Cord (220V Class 2)	1
	0B08666A	Power Cord (Australia)	1
	0B08348A	Power Cord (UK)	1
02	0B08037U	Cord Bushing (U.S.A., Canada, Japan, 220V Class 2 & Others)	1
	0B08719A	Cord Bushing (Australia)	1
	0B08351A	Cord Bushing 4K-4 (UK)	1
03	0H03779D	Rear Panel	1
04	0B08687A	6P DIN Socket	1
05	0B06623A	Power Transformer (U.S.A. & Canada)	1
	0B06622A	Power Transformer (Japan)	1
	0B06624A	Power Transformer (220V Class 2, UK & Australia)	1
	0B06625A	Power Transformer (Others)	1
06	0C01162B	Bolt Receptacle Plate	2
07	0J04076A	Power Switch Holder	1
08	0B07299A	Power Switch (U.S.A. & Canada)	1
	0B07301A	Power Switch (Japan)	1
	0B07252A	Power Switch (220V Class 2, Australia, UK & Others)	1
09	0J03663C	Switch Cover (U.S.A., Canada, Japan, 220V Class 2, UK & Australia)	1
	0M03946A	Voltage Selector Lock Plate C (Others)	1
10	0M03551B	Pass Label	1
11	0M03794A	Voltage Label 100V (Japan)	1
	0M03796A	Voltage Label 220V (220V Class 2)	1
	0M03797A	Voltage Label 240V (UK & Australia)	1
	0M03955A	Voltage Label 120V/220—240V (Others)	1
*12	0M04097B	Fuse Caution Label (U.S.A. & Canada)	1
13	0B07092U	Voltage Selector (Others)	1
* —	0M03844B	Power Cord Label (UK)	1
—	0F01071A	Free-up Belt	1
* —	0M04055A	SDNF Label (220V Class 2)	1
* —	0M03865A	SEV Label (220V Class 2)	1
—	0M04069B	Serial Number Plate	1
* —	0M03798A	Nakamichi Label (Japan)	1
L01	0E00714A	Screw M2.6x6 Philips Binding Head (Bronze)	2
L02	0E00756A	Screw M4x8 Philips Binding Head (Bronze)	2
L03	0E00860A	BT Screw M3x6 Philips Binding Head (Black Chromate)	1
L04	0E00502A	Screw M3x5 Philips Pan Head	2
L05	0E00593A	Screw M3x6 Philips Binding Head (Bronze)	2
L06	0E00507A	Nut Hex. M3	2
—	0J03644A	Chobert Rivet	2
		*: Depends on the versions.	
E01	**CA08117B**	**Reel Motor Ass'y**	**1**
01	0C08218A	Reel Motor	1
02	0C08063F	Reel Motor Pulley	1
E02	**CA08124A**	**Control Motor Ass'y**	**1**
01	0C08137A	Control Motor	1
02	0C08064A	Control Motor Pulley	1
03	0B09292A	Ceramic Capacitor 0.1μ 50V	2
04	0M03985A	Control Motor Label	1
05	0M03988A	Motor Seal B	1
F01	**CA08120A**	**Head Mount Base Ass'y**	**1**
01	0C08028C	Head Height Adjustment Gear	1
02	0C08027E	Head Height Adjustment Screw	2
03	0C08026D	Azimuth Alignment Screw	1
04	0C08161B	Spring Stopper	1
05	0C08131C	Head Plate Spring	1
06	CA08083C	Head Mount Base Sub Ass'y	1
07	CA08144A	RP-9E Record/Playback Head Ass'y	1
F02	**CA08053B**	**Supply Pressure Roller Ass'y**	**1**
01	0C08164G	Pressure Roller	1
02	0C08189B	Supply Tape Guide	1
03	CA08061A	Supply Pressure Roller Arm Ass'y	1
L01	0E00042A	E-Ring 1.5mm	1
L02	0C08024A	Washer 2mm	2
L03	0E00788A	BT Screw M2x8 Philips Pan Head	1
F03	**CA08079B**	**Take-up Pressure Roller Ass'y** Serial No.: A304.516074 —	**1**
01	0C08164G	Pressure Roller	1
02	0C08181C	Take-up Tape Guide	1
03	CA08073B	Take-up Pressure Roller Arm Ass'y	1
L01	0E00042A	E-Ring 1.5mm	1
L02	0C08024A	Washer 2mm	2
L03	0E00788A	BT Screw M2x8 Philips Pan Head	1
F03	**CA08079A**	**Take-up Pressure Roller Ass'y** Serial Nos.: A304.501001 — A304.516073	**1**
01	0C08164G	Pressure Roller	1
02	0C08181B	Take-up Tape Guide	1
03	CA08073B	Take-up Pressure Roller Arm Ass'y	1
L01	0E00042A	E-Ring 1.5mm	1
L02	0C08024A	Washer 2mm	2
L03	0E00788A	BT Screw M2x8 Philips Pan Head	1

9.13. Reel Motor Ass'y (E01)



Fig. 9.13

9.14. Control Motor Ass'y (E02)



Fig. 9.14

9.15. Head Mount Base Ass'y (F01)



Fig. 9.15

9.16. Supply Pressure Roller Ass'y (F02)



Fig. 9.16

9.17. Take-up Pressure Roller Ass'y (F03)



Fig. 9.17

9.18. Head Base Ass'y C (F04)



Fig. 9.18

9.19. Cassette Case Holder L Ass'y (F05)



Fig. 9.19

9.20. Cassette Case Holder R Ass'y (F06)



Fig. 9.20

9.21. Auto Shut-off Ass'y (F07)



Fig. 9.21

9.22. Pneumatic Damper Ass'y (F08)



Fig. 9.22

9.23. RP-9E Record/Playback Head Ass'y (G01)



Fig. 9.23

Schematic Ref. No.	Part No.	Description	Q'ty
F04	**CA08121A**	**Head Base Ass'y C**	**1**
01	GA02017A	E-8L Erase Head	1
02	0C08158D	EH Hold Plate	1
03	0C08166A	EH Hold Plate Spring	1
04	0C08174C	Cassette Hold Spring	1
05	CA08003P	Head Base Ass'y	1
06	0C08175A	Head Base L Spring	3
07	0B08679D	2P-H Connector	1
L01	0E00889A	Screw M1.7x8 Philips Pan Head	2
L02	0E00909A	Screw M2x6 Philips Pan Head	3
L03	0E00117A	Washer 2mm	3
L04	0E00853A	BT Screw M2x3 Philips Pan Head	1
F05	**CA08141A**	**Cassette Case Holder L Ass'y**	**1**
01	0C08073C	Lid Arm A	1
02	0C08114A	Lid Arm Spring	1
03	CA08090F	Cassette Case Holder L Sub Ass'y	1
L01	0E00837A	Stopper Ring 3mm	1
F06	**CA08022A**	**Cassette Case Holder R Ass'y**	**1**
01	0C08133A	Eject Sensor	1
02	CA08044A	Cassette Case Holder R Sub Ass'y	1
L01	0E00840A	BT Screw M2x8 Philips Pan Head	2
F07	**CA08119A**	**Auto Shut-off Ass'y**	**1**
01	0C08047A	Shut-off Pulley A	1
02	0C08206B	Shut-off Pulley B	1
03	0C08088B	Shut-off Pulley Shaft	1
04	0C08207B	Shut-off Pulley Holder	1
05	BA04127A	Shut-off P.C.B. Ass'y	1
F08	**CA08030A**	**Pneumatic Damper Ass'y**	**1**
01	0C08058C	Damper Piston	1
02	0C08102B	Damper Ring	1
03	0C08010C	Damper Plate	1
04	0C08059D	Sylinder	1
L01	0E00874A	Stopper Ring CS 2mm	1
G01	**CA08144A**	**RP-9E Record/Playback Head Ass'y**	**1**
01	0C08217A	Head Plate	1
02	0G01294A	RP-9E Record/Playback Head	1
03	0C08216B	Pad Lifter 9E	1
04	0B07857A	Head Terminal P.C.B.	1
05	0B08678C	4P-H Connector	1
L01	0E00887A	Screw M1.7x4 Philips Pan Head	1

10. OVERALL TIMING CHART

Mode	PLAYBACK			RECORD				
Control Button	Stop	Play	Stop	Rec	Rec/Play	Rec/Pause	Rec/Play	Stop
Tape		470ms / 300ms	120ms / 180ms		840ms / 740ms	130ms / 160ms	220ms / 120ms	130ms / 160ms
Output		300ms			560ms			
Bias					560ms			

Fig. 10

11. EQ. AMP. FREQUENCY RESPONSE

11.1. Playback Frequency Response



Fig. 11.1

11.2. Record Current Frequency Response



Fig. 11.2

12. WIRING DIAGRAM



Fig. 12.1

Note: Table of colors

BLK – Black
BLU – Blue
ORN – Orange
GRY – Gray
GRN – Green
RED – Red
BRN – Brown
YEL – Yellow
WHT – White
VIO – Violet


Remote
BLU
RED
ORN
BRN
GRY
GRN
Headphone Jack
WHT(W)
WHT(B)
BLK (B)
RED
WHT
Main P.C.B. Ass'y
(Component Side)
CN-3
CN-4
CN-2
Power Switch
AC Input
BRN
BLU
Power
Transformer
GRN
YEL
BLK
U.S.A. & CANADA (120 V)
Switch P.C.B. Ass'y
(Component Side)
BLK (W)
RED (W)
WHT(R)
BLK(R)
FC-E
CN-1
RED (R)
Volume P.C.B. Ass'y
(Component Side)
Control Switch P.C.B. Ass'y
(Component Side)
Shut-off P.C.B.
Ass'y
(Component Side)
Control P.C.B. Ass'y
(Component Side)
VIO
GRY
ORN
Lamp P.C.B. R Ass'y
(Component Side)
Lamp P.C.B. L Ass'y
(Component Side)
Rch
Level Meter
Lch
Record/Playback
Head
Erase
Head
Counter Switch
Control Motor
Eject Switch
Control Volume
Capstan Motor
Reel Motor
Record Protector
Switch

Fig. 12.2

13. BLOCK DIAGRAMS

13.1. Amplifier



Fig. 13.1

13.2. Mechanism Control



Fig. 13.2

14. SCHEMATIC DIAGRAMS



Fig. 14.1 Dolby NR IC μA7300PC



Fig. 14.2 Operational Amp. IC 4558



Fig. 14.3.1 Serial No.: A304.518705 –

Notes: 1. Diode is 1SS53, 1S953, or 1S1555 unless o
2. Resistor and capacitor marked with * show





Switch Chart	
Description	Schematic Ref. Number
Record / Play	SW301
MPX	SW302
Dolby NR	SW303
ZX	SW304
SX / EX	SW305
Eq.	SW306
Memory	SW401

Fig. 14.3.1 Serial No.: A304.518705 –

Notes: 1. Diode is 1SS53, 1S953, or 1S1555 unless otherwise specified.
2. Resistor and capacitor marked with * show typical value.



Fig. 14.3.2 Serial Nos.: A304.501001 – A304.518704





Switch Chart	
Description	Schematic Ref. Number
Record / Play	SW301
MPX	SW302
Dolby NR	SW303
ZX	SW304
SX / EX	SW305
Eq.	SW306
Memory	SW401

Fig. 14.3.2 Serial Nos.: A304.501001 – A304.518704

Notes: 1. Diode is 1SS53, 1S953, or 1S1555 unless otherwise specified.
2. Resistor and capacitor marked with * show typical value.

15. SPECIFICATIONS

Power Source	100, 120, 120/220-240, 220 or 240 V; 50/60 Hz (according to country of sale)
Power Consumption	23W Max.
Tape Speed	1-7/8 ips. (4.8 cm/sec.)
Wow-and-Flutter	Less than 0.12% WTD Peak, 0.06% WTD rms
Frequency Response	20-18,000 Hz ±4 dB (–20 dB Rec. Level)
Signal-to-Noise Ratio (Dolby NR In, 70 μs)	Better than 62 dB at 400 Hz, 3% THD, WTD rms
Total Harmonic Distortion	Less than 1.0% at 400 Hz, 0 dB (ZX, EXII Tapes) Less than 1.2% at 400 Hz, 0 dB (SX Tape)
Erasure	Better than 60 dB below saturation level at 1 kHz
Separation	Better than 36 dB at 1 kHz, 0 dB
Crosstalk	Better than 60 dB at 1 kHz, 0 dB
Bias Frequency	105 kHz
Input	50 mV, 30 k ohms
Output Level	600 mV (400 Hz, 0 dB) 2.2 k ohms
Headphone	10 mW (400 Hz, 0 dB) 8 ohms
Dimensions	450(W) x 135(H) x 289(D) m/m 17-23/32(W) x 5-5/16(H) x 11-3/8(D) inches
Approximate Weight	6.4 kg, 14 lb 2 oz.

- Specifications and appearance design are subject to change for further improvement without notice.
- Dolby NR under license from Dolby Laboratories.
- The word "Dolby" and the Double-D-Symbol are trademarks of Dolby Laboratories.